



HMS MODEL 1050

INSTALLATION MANUAL

**OnQ**



HMS MODEL 1050

INSTALLATION MANUAL

Document Number 889153 Rev B  
November, 1999  
Copyright © 1999 HAI  
All Rights Reserved

# CONTENTS

<b>INTRODUCTION .....</b>	<b>1</b>
<b>PLANNING .....</b>	<b>1</b>
<b>INSTALLATION.....</b>	<b>3</b>
<b>CONTROLLER HOOKUP .....</b>	<b>3</b>
<b>ABOUT SECURITY ZONES .....</b>	<b>5</b>
BURGLAR ZONE HOOKUPS .....	5
FIRE ZONE HOOKUP .....	5
<b>TELEPHONE CONNECTIONS.....</b>	<b>8</b>
<b>LCD KEYPAD HOOKUP .....</b>	<b>10</b>
<b>KEYPAD SETUP.....</b>	<b>10</b>
KEYPAD ADDRESS .....	10
SOUNDER .....	10
KEY CLICK .....	11
KEY BACKLIGHT .....	11
VIEWING ADJUSTMENT.....	11
LANGUAGE .....	11
EXIT SETUP MODE .....	11
<b>KEYPAD SELF TEST .....</b>	<b>11</b>
<b>SOUNDER OUTPUTS.....</b>	<b>13</b>
INTERIOR SOUNDER HOOKUP .....	13
EXTERIOR SOUNDER HOOKUP .....	14
<b>CONTROLLER OUTPUTS .....</b>	<b>15</b>
GENERAL PURPOSE SWITCHING APPLICATIONS.....	15
SOUNDER TRIGGERING .....	15
COMMUNICATOR OUTPUTS .....	15
"ARMED" AND "OK TO ARM".....	16
OnQ COMMUNICATING THERMOSTATS.....	16
<b>REMOTE ARM/DISARM SWITCH .....</b>	<b>16</b>
<b>HOME CONTROL MODULES .....</b>	<b>16</b>
<b>OUTDOOR TEMPERATURE, TEMPERATURE SENSORS.....</b>	<b>18</b>
<b>SYSTEM POWER UP PROCEDURE .....</b>	<b>19</b>
<b>KEYPAD CHECK OUT .....</b>	<b>19</b>
<b>TELEPHONE CHECK OUT .....</b>	<b>20</b>
<b>BURGLAR ZONE CHECK OUT.....</b>	<b>20</b>
<b>FIRE ZONE CHECK OUT .....</b>	<b>21</b>
<b>HOME CONTROL CHECKOUT .....</b>	<b>21</b>
<b>CUSTOMER CHECKOUT .....</b>	<b>22</b>
<b>IN CASE OF TROUBLE .....</b>	<b>22</b>
KEYPADS.....	22
CONTROLLER.....	22
<b>X-10 TROUBLESHOOTING TIPS .....</b>	<b>24</b>
<b>DIGITAL COMMUNICATOR.....</b>	<b>25</b>
<b>DESCRIPTION OF 4/2 FORMAT .....</b>	<b>25</b>
<b>3/1 FORMAT .....</b>	<b>26</b>
<b>OPENING AND CLOSING REPORTS.....</b>	<b>26</b>

<b>INSTALLER SETUP .....</b>	<b>27</b>
<b>SETUP CONTROL .....</b>	<b>27</b>
X-10 HOUSE CODE .....	27
X-10 3-PHASE .....	27
OUTPUT TYPES .....	28
<b>SETUP ZONES.....</b>	<b>32</b>
ZONE EXPANSION .....	32
ZONE RESPONSE TIME .....	32
ZONE TYPES .....	33
LATCHING ZONE TYPES .....	33
DESCRIPTION OF ZONE TYPES.....	33
<b>SETUP DIGITAL COMMUNICATOR.....</b>	<b>37</b>
FIRST PHONE NUMBER, FIRST ACCOUNT NUMBER .....	37
SECOND PHONE NUMBER, SECOND ACCOUNT NUMBER .....	37
COMMUNICATOR TYPE .....	37
TWO-WAY AUDIO.....	37
REPORT OPEN/CLOSE .....	38
AUTOMATIC TEST TIME .....	38
ALARM CODES .....	38
<b>SETUP AREAS.....</b>	<b>39</b>
SETUP AREAS: CONTROL .....	39
SETUP AREAS: ZONES .....	41
SETUP AREAS: BUTTONS.....	42
SETUP AREAS: KEYPADS.....	42
SET-UP AREAS: THERMOSTATS.....	43
SETUP AREAS: MESSAGES .....	43
<b>SETUP TEMPERATURES .....</b>	<b>44</b>
TEMPERATURE DISPLAY.....	44
THERMOSTAT TYPE .....	44
<b>SETUP MISCELLANEOUS .....</b>	<b>45</b>
INSTALLER CODE.....	45
ENABLE PC ACCESS.....	45
PC ACCESS CODE .....	45
CALL BACK PHONE NUMBER.....	45
OUTSIDE SIREN DELAY .....	46
DIAL OUT DELAY .....	46
ALARM RESET TIME .....	46
ARMING CONFIRMATION.....	46
FIRE ALARM VERIFICATION .....	47
ENABLE EMERGENCY KEYS .....	47
TIME DISPLAY .....	48
DATE DISPLAY.....	48
AC POWER FREQUENCY .....	48
DEAD LINE DETECT .....	48
OFF HOOK DETECT .....	48
PICKUP AFTER HANGUP .....	48
CLOCK ADJUSTMENT.....	49
MODEL AND SOFTWARE VERSION .....	49
RESET SYSTEM EEPROM .....	49
RESET SYSTEM RAM .....	49
<b>SETUP EXPANSION.....</b>	<b>50</b>
MODULE 1 TYPE .....	50

MODULE 2 TYPE - MODULE 4 TYPE .....	50
SERIAL 1 RATE .....	50
SERIAL 2 RATE .....	50
<b>MODEL 1050 SPECIFICATIONS .....</b>	<b>51</b>
<b>UNDERWRITER'S LABORATORIES (UL) INSTALLATION REQUIREMENTS. ....</b>	<b>52</b>
<b>24-HOUR STANDBY BATTERY CAPACITY .....</b>	<b>53</b>
<b>SMOKE DETECTOR INSTALLATION GUIDELINES .....</b>	<b>54</b>
<b>MODEL 1050 INSTALLATION PLANNER / CHECKLIST .....</b>	<b>55</b>
<b>DIGITAL COMMUNICATOR CODE SHEET.....</b>	<b>75</b>

## FIGURES

Figure 1 - Controller Hookup .....	4
Figure 2 - Overall Connections Diagram .....	6
Figure 3 - Fire Zone Connections .....	7
Figure 4 - RJ31X Jack Connections.....	9
Figure 5 - Keypad Connections .....	12
Figure 6 - Interior Sounder Connections .....	13
Figure 7 - Exterior Sounder Connections .....	14
Figure 8 - Remote Keyswitch Connections .....	17
Figure 9 - 24 Hour Standby Connections.....	53

## **INTRODUCTION**

This installation guide is intended as an aid to installing the HMS Model 1050. The installer should also have thoroughly reviewed and understood the Model 1050 Owner's Manual, which has important information regarding final setup of the system. This manual assumes that the installer has a basic understanding of installing a security system.

This guide applies to the 363432-01 version of the Model 1050 series controller. Refer to the Underwriters Laboratories Installation Requirements section for details in the application of each. Failure to install the Model 1050 and its accessories in accordance with the UL Requirements in this manual and in the Owner's Manual, is a violation of the Listing Mark.

## **PLANNING**

Before you start, your system should be planned. The INSTALLATION PLANNER/CHECKLIST at the end of this manual serves two purposes: First, to help you plan out your system, and second, to perform a final check out once installation is complete.

Use the PLANNER/CHECKLIST as follows:

1. Zones:

- Decide where each contact or detector will be located
- Decide which zone it will occupy
- Decide zone type for each zone
- Decide what area will be assigned
- With the customer, decide what text and voice descriptors will be used. Consult table of voice descriptors, so that you can choose similar words for the text to avoid customer confusion.
- Write each contact location on the line under the appropriate zone on the PLANNER/CHECKLIST
- See SMOKE DETECTOR INSTALLATION GUIDELINES to plan locations for smoke detectors

2. Keypads:

- Consult the customer on the keypad location. The keypad should be easily accessible. Write the keypad location(s) on the planning sheet.

3. Interior Sounder and Outside Siren:

- Locate both where they cannot be tampered with.

4. Home Control Modules:
  - Keep in mind that the Model 1050 default settings for FLASH FOR ALARM is Unit Number 2 - make that the front porch light.
5. Plan for thermostats and other options.
6. Give consideration to where the controller will go. Remember that it needs an unswitched, duplex receptacle, preferably on its own circuit, within 5 feet of the controller.

## INSTALLATION

Go over your plan with your customer.

1. Install the entire system. Refer to sections in this manual to see how to install various components.
2. Follow the Power-Up and Checkout procedures.
3. Explain the basics to the customer. Deliver all manuals and documentation.
4. Pick up trash, tools, and payment.
5. Follow up with your customer to keep them satisfied.

## CONTROLLER HOOKUP

1. When choosing a place to mount the controller, consider the following:
  - a. A duplex outlet, preferably on its own circuit, is required to be within 5 feet of the controller for the power transformer and the X-10 Control Module.
  - b. The controller should be protected from weather, temperature extremes, and burglars.
  - c. The controller makes a faint hissing sound during normal operation. It may not be suitable for mounting in a quiet bedroom.
2. GROUND THE CONTROLLER "EARTH GND" TERMINAL TO A COLD WATER PIPE OR TO A 4 FOOT GROUND ROD TO PRESERVE ITS BUILT-IN TRANSIENT PROTECTION. USE 14 GAUGE WIRE. TRANSIENT PROTECTION WILL NOT WORK IF THE CONTROLLER IS NOT PROPERLY GROUNDED.
3. Connect the 24 VAC power transformer to the 24 VAC INPUT terminals.
4. Connect the BLACK battery wire to the minus (-) terminal on the battery. DO NOT connect the red wire at this time. DO NOT reverse the connections; the battery fuse will blow. Note that the unit will NOT START on the battery alone. AC power must be applied to engage the low voltage cut out relay. After that, the system will run on the battery without AC power.
5. Plug the X-10 USA Powerline Interface Module into the outlet above the transformer. Use the supplied 4 conductor modular telephone cable to connect the module to the jack on the processor board. DO NOT ATTEMPT TO LENGTHEN THIS CABLE! The X-10 modules may not work! The red LED on the interface module should be on and will blink off when the interface receives a signal from the controller.
6. Refer to **FIGURE 1 (CONTROLLER HOOKUP)** for this configuration.






Figure 1 - Controller Hookup

## ABOUT SECURITY ZONES

Each of the 16 security zone inputs in a Model 1050 may be configured as a burglary zone, a fire zone, a temperature zone, or an auxiliary input. The zone type for each zone is selected through the Model 1050 SETUP menu on the keypad or by using the PC ACCESS software.

The system supports a maximum zone resistance, excluding the end-of-line resistor, of 150 ohms.

The default settings for all zone inputs on a Model 1050 controller are configured as Auxiliary inputs.

## BURGLAR ZONE HOOKUPS

The Model 1050 system supports both normally open and normally closed switches. Most contacts designed for doors, windows, motion detectors, glassbreak detectors and other security devices meet this requirement. An external 1000-ohm end-of-line resistor must be used for all burglary zones.

1. When using a normally open switch, a 1000-ohm end-of-line resistor must be in parallel with the zone being used. Maximum loop resistance excluding end-of-line resistor should not exceed 150 ohms.
2. When using a normally closed switch, a 1000-ohm end-of-line resistor must be put in series with the zone being used. Maximum loop resistance excluding end-of-line resistor should not exceed 150 ohms.
3. Power motion detectors from AUX 12VDC.
4. Unused zones may be left open, and should be left at the default setting of AUXILIARY zone types.
5. Use normally open or normally closed panic switches with a 1000-ohm end-of-line resistor.
6. See **FIGURE 2 (OVERALL CONNECTIONS DIAGRAM)** for configurations of burglary zones.

## FIRE ZONE HOOKUP

The Model 1050 system supports normally open (closed for alarm), four-wire smoke detectors. An external 1000-ohm end-of-line resistor must be used for all fire zones.

1. Use normally open (closed for alarm) 4 wire 'SYSTEM' type smoke detectors, ESL Model 445AT or equivalent, rated 8 - 14 VDC.
2. Power smoke detectors from SWITCH +12 VDC.
3. End of line resistor: 1000 ohms. Maximum loop resistance EXCLUDING end of line resistor is 150 ohms. Use Model 1503A0011 End of Line Resistor Assembly in UL Listed Installations.
4. End of Line Relay Module (ESL Model 204B or equiv.) required for UL installations.
5. Refer to **FIGURE 3 (FIRE ZONE CONNECTIONS)** for this configuration.




Figure 2 - Overall Connections Diagram




Figure 3 - Fire Zone Connections

## TELEPHONE CONNECTIONS

1. If an RJ31X jack has been supplied by the telephone company, it is probably wired correctly and the controller can be connected by plugging the supplied 8 conductor telephone cable into the RJ31X jack. The other end of the cable is spaded. The green, red, brown, and gray wires must be connected to the controller at the designated terminals under the section of the board marked 'PHONE'.
2. If required, install the supplied RJ31X jack as shown in the following diagram. The polarity must be correct for proper operation of the phone access feature.
3. IT IS IMPERATIVE THAT THE PHONE LINE COMING INTO THE HOUSE BE CONNECTED TO A GROUNDED SURGE ARRESTOR OUTSIDE THE PREMISES. IT IS THE RESPONSIBILITY OF THE TELEPHONE COMPANY TO PROVIDE THIS SURGE ARRESTOR.
4. INSPECT THE INCOMING PHONE LINES. THE FIRST THING THAT THEY SHOULD GO TO IS A SMALL BOX ON THE OUTSIDE OF THE PREMISES. THERE SHOULD BE A HEAVY GROUND WIRE COMING FROM THIS BOX GOING TO A COLD WATER PIPE OR A SEPARATE GROUNDING ROD.
5. IF THERE IS NO SURGE ARRESTOR OR IF THE GROUND WIRE IS MISSING, HAVE THE CUSTOMER INSIST THAT THE TELEPHONE COMPANY INSTALL ONE FOR THE SAFETY OF THE CUSTOMER.
6. WHEN WIRING A RJ31X JACK, MAKE SURE THAT THE INCOMING PHONE LINES GO TO THE TELEPHONE COMPANY SURGE ARRESTOR BEFORE THEY GO TO THE RJ31X JACK.
7. When the RJ31X is installed as shown, locate the green, red, brown, and gray spaded wires from the 8 conductor phone cable and connect to the section on the Model 1050 controller marked 'PHONE'. Plug the modular end of the cable into the RJ31X jack. If necessary, bend the tab up on the plug to ensure a tight fit that will not fall out.
8. Verify the following if you have trouble during check out: With the system running, the RJ31X jack properly connected and all phones on-hook (hung up), the PHONE LINE LED, located in the upper left corner of the controller, should be OFF. If it is on, reverse the RED and GREEN wires to both the house phones and the telephone company wires at the RJ31X jack. When the receiver is picked up on any phone, the PHONE LINE LED will come on. When the phone line rings, the PHONE LINE LED will light.
9. If the Model 1050 is accessed on an in house telephone, the Model 1050 will disconnect the phones from the phone company lines and supply its own talk voltage to the phones. The PHONE LINE LED will be on in this case.
10. Refer to **FIGURE 4 (RJ31X JACK CONNECTIONS)** for this configuration.




Figure 4 - RJ31X Jack Connections

## LCD KEYPAD HOOKUP

1. 16 LCD Keypads (Models 363713-01, 02, 03, and 04) MAXIMUM per system, subject to power availability.
2. Use 4-conductor 22-gage wire, 1000 feet maximum length. Keypads can be homerun or daisy chained. This length shall be divided by the total number of keypads at the end of the run. For example, for 8 keypads, the maximum length reduces to 125 feet. All LCD Keypads are connected to the same 4 wires, +12, GND, A, B.
3. The keypad should be mounted so that the LCD display is at or slightly above eye level. Keypads should be kept out of the reach of young children. A good height is approximately 58 inches from the floor to the bottom of the keypad enclosure.
4. Remove keypad face from back plate (slots on bottom of keypad will release back plate, use a screwdriver). Mount the back plate to the wall. Mounting holes are designed to fit on a single or double gang box, or directly to the wall. Pull the wires from the wall through the opening in the back plate. Splice the wires to the supplied cable. Connect the cable to the connector on the keypad board (J1). Snap the keypad face on to the back plate.
5. Refer to **FIGURE 5 (KEYPAD CONNECTIONS)** for this configuration.

## KEYPAD SETUP

The keypad has different operating options that can be setup from the keypad to the user's preference. If more than one keypad is being used, it is required that you give each keypad a different address. You can change the address of a keypad through the keypad setup mode.

To enter the keypad setup mode, simultaneously press and hold the 4 and up arrow (↑) for approximately 1 second. The keypad will beep 5 times and enter the setup mode. The top line of the display will indicate what you are doing, followed by the current setting. The bottom line will show a menu of your options. To the lower right corner of the display is the direction arrow(s). Where possible, the up (↑), down (↓), and two-headed (↕) arrow characters are shown on the keypad display to indicate which arrow keys may be pressed at that time. Press the down arrow (↓) key to advance to the next item. Press the up arrow (↑) key to go back to the previous item.

## KEYPAD ADDRESS

If you are installing more than one keypad, each keypad must be set to a different address. The default address setting is (1) - this is adequate if only one keypad is being used. The choices at the bottom are 1-16, however, the Model 1050 only supports 8 keypads. When making your choice, choose an address between 1-8, then press the # (pound) key.

## SOUNDER

If you wish not to hear the beeper in the keypad for any reason, the sounder option can be turned off. Select (0) for OFF or (1) for ON, then press the # key.

## **KEY CLICK**

The sounder makes a click every time a key is pressed. This option may also be turned off. Select (0) for OFF or (1) for ON, then press the # key.

## **KEY BACKLIGHT**

The keys on the keypad are lit. The keys can be never lit, always lit, or only lit when the LCD display is lit. Select (0) OFF, (1) for ON, or (2) TIMED, then press the # key.

## **VIEWING ADJUSTMENT**

This option is an adjustment for the viewing angle of the LCD display. This has been set to its best value at the factory, however, you may wish to tweak it. The display has 20 levels of adjustment. Select (1) for a lower viewing angle, or (2) for a higher viewing angle.

## **LANGUAGE**

This option is to display the 'keypad setup' text on the LCD display in English, French, Italian, or Spanish. Select one of the languages, then press the # key.

## **EXIT SETUP MODE**

To exit Setup Mode, press and hold the 4 and up arrow (↑) keys simultaneously for about 1 second. The keypad will return to normal operation. You may need to press (\*) to restore the display.

## **KEYPAD SELF TEST**

Use the self test mode to verify the proper operation of the keypad.

1. Disconnect the keypad from the controller. Connect +12 and GND terminals to a 12-volt source (or a fresh 9-volt transistor battery.) The keypad beeper will beep twice per second, the LCD backlight and the keypad key will be lit, and the LCD will display "NO CONTROLLER DATA".
2. Simultaneously press and hold the 7 and the down arrow (↓) keys for approximately 3 seconds. The beeper will beep 5 times, the LCD backlight and keypad backlight will turn off, and the display will clear. The LED at the top right corner of the keypad will start to cycle through its different colors (red, green, yellow, then turns off). At the end of each cycle the beeper will beep once.
3. Press any key. The LCD backlight and the keypad key backlight will turn on.
4. Press the keys in the following order and verify that the appropriate character fills the screen. 0 - 9, \*, #, AWAY (A), NIGHT (B), DAY (C), OFF (D), ↑ (filled blocks), and ↓ (blanks).
5. If this is successful, the keypad is good. Simultaneously press and hold the 7 and down arrow (↓) keys to exit the self test mode or disconnect power.





## SOUNDER OUTPUTS

Sounders can draw up to 1 amp **MAXIMUM**, split between the Interior and Exterior Horn Outputs. Use a relay connected directly to the battery if higher current is required.

### INTERIOR SOUNDER HOOKUP

1. Locate the interior sounder in a central location. The sounder is very loud. Do not install it in a room where small children or animals could be trapped if the alarm is activated.
2. For UL Listed residential fire alarm applications, the UL Listed Wheelock Model 34T-12 fire horn must be used and supervised as shown under **INTERIOR SOUNDER CONNECTIONS**. The zone for horn supervision (Zone 5 shown here) must be configured as a **FIRE TAMPER** zone type.
3. Refer to **FIGURE 6 (INTERIOR SOUNDER CONNECTION)** for connections.




Figure 6 - Interior Sounder Connections

## EXTERIOR SOUNDER HOOKUP

1. If used, wire tamper switches to a tamper zone with a 1000-ohm end-of-line resistor.
2. Refer to **FIGURE 7 (EXTERIOR SOUNDER CONNECTION)** for connections.




Figure 7 - Exterior Sounder Connections

## CONTROLLER OUTPUTS

The Model 1050 provides 8 programmable hardwired voltage outputs and two horn voltage outputs. These outputs are programmable for the following output types:

- General Purpose low voltage switching applications (12 VDC) - Units 32 - 40
- Sounder triggering (a trigger for siren and voice drivers for BURG and FIRE)
- Communicator outputs (radio, cellular, or any other type of auxiliary communicator)
- 'ARMED' and 'OK TO ARM' outputs
- OnQ Communicating Thermostats (Output 8)

Outputs 1 - 8 can supply a **maximum** of 100 mA each. These outputs are included in the total DEVICES load, which cannot exceed 1A. The HORN outputs can supply a **maximum** of 1A each. HORN outputs are included in the total HORNS load, which can not exceed 1A.

## GENERAL PURPOSE SWITCHING APPLICATIONS

This output will supply 12 VDC to the output terminal when its corresponding unit is ON. Output 1 is designated Unit 33, Output 8 is Unit 40. This can be used to drive relays for many different applications, including switching sprinkler valves and low-voltage lighting.

## SOUNDER TRIGGERING

This output can be used as a trigger for siren and voice drivers. When a driver requires a separate input for burglary and fire, you can configure this output to give a voltage trigger to the driver. Also, each area can have its own sounder.

## COMMUNICATOR OUTPUTS

This output can be used for radio communications or any other type of auxiliary communications to augment the built-in digital and voice dialers. Any communications device can be used with the Model 1050, provided that it is powered by 12 VDC, has 12 VDC triggered inputs, and has 2 (or more) channels.

The 'Communicator' outputs are activated 3 seconds before the Model 1050 dialer begins to dial, either using its built-in digital dialer or voice dialer.

The following events will activate the BURG output: Burglar alarms (including panic zones), Auxiliary emergencies, Police emergencies, and Duress alarms. Fire alarms and the fire emergencies will activate the FIRE output.

## "ARMED" AND "OK TO ARM"

**ARMED:** When the system is armed in any of the security modes (AWAY, NIGHT, or DAY), this output will be active. It is typically used to activate a red LED to indicate that the system is 'armed'.

**OK TO ARM:** When all security zones are secure, no zones are bypassed, and the system is in the 'OFF' mode, this output will be active. It is typically used to activate a green LED to indicate that the system is 'ok to arm'.

## OnQ COMMUNICATING THERMOSTATS

When OnQ thermostats are used, Output 8 is configured to communicate with up to 64 thermostats.

## REMOTE ARM/DISARM SWITCH

1. If desired, a remote keyswitch, keypad, or hidden arm/disarm toggle can be connected to the system. The device should have a momentary close type switch.
2. Configure one of the zone inputs as an ARM/DISARM TOGGLE zone. A closure of the switch contacts will toggle the arming mode between OFF and AWAY (Entry and Exit delays are still active).
3. Configure one of the outputs as an "ARMED" and another output as an "OK TO ARM" output. These outputs are used to activate a red or a green LED based on the state of the alarm system. The "ARMED" and "OK TO ARM" outputs can supply a maximum of 100 mA each. These outputs are included in the total DEVICES load, which cannot exceed 1 A.
4. Refer to **FIGURE 8 (REMOTE KEYSWITCH CONNECTION)** for this configuration.

NOTE: In UL Listed Installations, the Listed Ademco Model 9789 keyswitch shall be used.

## HOME CONTROL MODULES

Install X-10 or compatible modules EXACTLY as described in the instructions that come with each module. Watch the load ratings and types of load allowed. The Model 1050 is designed to send signals to any device compatible with the X-10 power line carrier protocol




Figure 8 - Remote Keyswitch Connections

## **OUTDOOR TEMPERATURE, TEMPERATURE SENSORS**

The OnQ HMS Temperature Sensor Module is a temperature sensor that mounts in an outdoor location, usually under an overhang, and sends the outdoor temperature to a Model 1050 system. It is coated with a sealant to withstand outdoor moisture. The outdoor temperature can be displayed on the keypad, spoken over the telephone, or displayed on an OnQ communicating thermostat.

1. Each OnQ HMS Temperature Sensor requires one zone input.
  - Program the zone type as an Outdoor Temperature (Type 81). It may also be programmed as a Temperature (Type 82), or Temperature Alarm (Type 83).
2. Plan to mount the OnQ HMS Temperature Sensor under an overhang or to the underside of an eave, otherwise known as the soffit, to protect it from direct sunlight and rain.
3. Run a 4-conductor wire from the controller to the selected location. Connect using the 3 B-GEL water tight wire splices. The green conductor is not used.
4. Mount the OnQ HMS Temperature Sensor using the 2 - #6 x 1/2" stainless steel self-tapping screws.

## **SYSTEM POWER UP PROCEDURE**

1. Carefully review hookups to the zones, grounds, sounders, and keypads.
2. Disconnect 1 lead of both the interior and exterior sounders.

NOTE: Follow this power up procedure to verify proper operation of the power supply, battery charger, and low voltage cut out relay.

3. The positive lead to the battery should be disconnected at this time. Make sure that the red battery wire is not touching anything.
4. Plug in the power transformer.
  - The AC ON LED should illuminate. The Model 1050 may make a faint hiss. This is normal.
  - The STATUS LED should begin blinking at a rate of 1 blink per second. This indicates that the Model 1050 processor and software are working.
  - The PHONE LINE LED should be OFF (if all telephones are on hook (hung up) and the RJ31X jack is properly connected).
5. Unplug the power transformer to kill the system. Connect the red battery wire to the + (positive) battery terminal. The system should not start.
6. Plug in the power transformer. The system should start.
7. Unplug the power transformer. The system should continue to run on the battery (as evidenced by the flashing STATUS LED)
8. Plug the transformer back in and secure it to the outlet.

## **KEYPAD CHECK OUT**

1. The keypad(s) should be operating. Press '\*' to silence the trouble beeper if it is beeping. Press OFF, 1, 1, 1, 1 (or the current User code) if the alarm is tripped. If the keypads are not operating properly, make sure that no two keypads have the same address, and check the wiring.
2. With all doors and windows closed, all motion detectors normal, the bottom line of the display should read SYSTEM OK. If there are any trouble indications that occurred during installation, press '\*' to acknowledge them and silence the beeper.
3. Set the time and date by pressing the 9, enter the Master Code, then 2 key. Enter the time on the keypad, then the DATE (enter date as 6 characters: January 1, 00 as 010100).
4. The keypad should now show the time and date on the top line, "SYSTEM OK" on the bottom line.



## **TELEPHONE CHECK OUT**

1. Verify that the Telephone Company surge arrestor is properly grounded.
2. Verify that the incoming telephone lines are run to the surge arrestor first, then from the surge arrestor to the RJ31X jack, then from the RJ31X jack to the house phones.
3. The PHONE LINE LED, on the controller, should be off when the phones are hung up.
4. Pick up an in-house phone, wait about 1 second, then press the '#' key. You should hear the Voice menu on the phone. If not, check to see that the RJ31X jack is properly wired and connected to the controller. There should be no interference from the Telephone Company while the menu is being read over the phone.
5. Record the owner's NAME and ADDRESS in the ADDRESS speech memory as shown in SETUP ADDRESS in the OWNER'S MANUAL (Press 8, 9, then 1111 or the current Master code to record the address).

NOTE: DO NOT record any TOUCH TONES in the ADDRESS!!

6. Check that all in-house phones are working.

## **BURGLAR ZONE CHECK OUT**

1. With all doors and windows closed, all motion detectors and security devices normal, you should have "SYSTEM OK" on the keypad.
2. If any zones are abnormal, check your wiring. If the battery indication is low, make sure that the battery is connected securely. Give the battery a chance to charge.
3. From the top-level display, have a partner go around the house and trip each sensor one at a time. The display should indicate the correct zone "NOT RDY" when the zone is tripped, then return to "SYSTEM OK" when the zone is secured. Be sure that the zone type indicated (ENTRY/EXIT, PERIMETER, ETC.) is correct for the zone being tested.
4. If the zone being checked is armed, (i.e. PANIC or TAMPER type, which is always armed) the alarm will be activated. Press OFF and 1111 or the current User code to silence the alarm, or bypass the PANIC and TAMPER zone(s) before you start.
5. Reconnect the sirens. Be sure that no one is standing near a siren. Activate the alarm, and ensure that both the inside and, after a delay, outside sirens activate.

## **FIRE ZONE CHECK OUT**

1. Press '\*' to return the keypad to the SYSTEM OK indication. Check the fire zone per the sensor manufacturer's instructions. The fire alarm should be activated (pulsing interior sounder, exterior siren).
2. Press '\*' to silence the alarm. The display will still indicate that the FIRE ZONE is in alarm.
3. Press DAY or NIGHT or AWAY and the User code to arm the system, then OFF and the User code to disarm. This arm/disarm cycle will reset the smoke detector. If the cause for alarm (i.e. smoke) has cleared, the display will return to SYSTEM OK.

NOTE: Be sure that the DIAL OUT DELAY is long enough so that you can cancel the alarm before the system dials out.

## **HOME CONTROL CHECKOUT**

1. Confirm that the HOUSE CODE on the Model 1050 is set to the same HOUSE CODE set on all of the modules (See SETUP CONTROL).
2. On the keypad press 4, 1 (ALL ON). All lamp type modules should go on. Note that appliance modules and auxiliary outputs do not respond to ALL ON.
3. On the keypad press 4, 2 (ALL OFF). All modules should go off. Note that auxiliary outputs do not respond to ALL OFF.
4. Operate each unit number individually and verify that it works. Write down its unit number and description on the PLANNING/CHECKLIST sheets.
5. Ensure that auxiliary inputs and outputs are working.

## **CUSTOMER CHECKOUT**

After you have completed the system check out and everything works, be sure that the customer knows how to:

1. Disarm/silence the system (OFF, 1111 or current User code). **HAVE THE CUSTOMER PRACTICE!**
2. Change the codes.
3. Get the menu over the in-house phones.

### **You should also:**

4. Demonstrate arming and disarming.
5. Demonstrate home control.
6. Demonstrate setup and programming.
7. Show him/her how to program the dial out numbers.
8. Deliver the Owner's Manual and copies of the Planning/Checkout sheets.
9. If the customer has subscribed to a central monitoring service, this should be explained to him/her.

## **IN CASE OF TROUBLE**

### **KEYPADS**

If you experience trouble that seems to be with a keypad, try disconnecting the keypad and running the keypad self test as described under KEYPAD HOOKUPS in this manual. If the keypad does not run the self-test properly, it should be returned to OnQ Technologies for repair.

"NO CONTROLLER DATA" or erratic operation of the LCD display could be a result of: A and B terminals connected backwards, poorly, or 2 or more keypads have the same address.

### **CONTROLLER**

Check the AC ON (bottom) LED. If it is not lit, check for 24 VAC at the transformer connections and the fuse on the controller board marked MAIN 2 A.

Check the STATUS (top) LED on the controller board. It should be blinking once per second, indicating the proper operation of the microprocessor and memory. If not, try powering the system down: Disconnect the power transformer and battery, then reconnect both. The status light should begin blinking.

If the AC ON LED is on and the STATUS light is still not blinking, check the AUX +12 V with a DC voltmeter. It should be 13.7 volts. If not, make sure that there isn't too much load on the system. Disconnect all loads. If the STATUS LED still won't blink, there is a problem with the controller board and it must be returned to OnQ Technologies for repair.

Phone line problems, or problems with the Model 1050 voice are usually the result of the RJ31X jack being improperly wired. Check RJ31X jack wiring and polarity carefully, as described in TELEPHONE CONNECTIONS.

In the event that the controller is found defective, the controller board can be removed without disconnecting the entire house wiring from their terminals. The terminal strips can be removed from the controller board. Then the controller (or processor board) can be repaired and reinstalled easily.

**Follow this procedure for removing the controller board:**

1. If possible, upload the programs and configuration. (This will not be possible if the status LED isn't flashing or if you can't get the voice to work.)
2. Unplug the power transformer.
3. Disconnect the battery
4. Disconnect the RJ31X modular cable at the jack!! (If you only disconnect it at the Model 1050 controller, the house phones won't work.)
5. Disconnect the X-10 cable.
6. Carefully remove the four terminal strips from the controller board. Gently push down on terminal strip retention clips. These clips are located on either end of the strip and 2 in the middle. Slowly pull strip away from terminal block socket and secure.
7. Remove 9 screws and washers; 3 on the top edge, 3 on the bottom edge, and 3 in the middle of the controller.
8. Remove the controller board.
9. Protect the back of the controller board with cardboard, pack carefully. OnQ Technologies will not be responsible for returned items damaged due to inadequate packaging.
10. Call OnQ Technologies, Inc. with the serial number for a return authorization number to help us track your return. Write the R. A. # on the outside of the package.
11. Return the controller to OnQ Technologies, Inc. Please include your return address, any special shipping instructions, and a daytime phone number so that we can reach you if we have any questions. Also include a brief description of the problem that you are having.
12. INSTALLATION: follow the removal process in reverse. Follow the POWER UP and CHECK OUT procedures in this manual.

**FOR HELP:** Call OnQ Technologies, Inc., between the hours of 8:00 AM and 5:00 PM Eastern Time, at (717) 702-2532.

## **X-10 TROUBLESHOOTING TIPS**

1. If any light does not work, check the HOUSE CODE on the module. It must be set to the same house code as the Model 1050.
2. Operate the module locally to ensure that power is getting to it. You should be able to turn the light or appliance on using its switch (turn it on, then off, then on again for plug in modules, press the on/off switch for wall switch modules.)
3. Three-way wall mounted lamp switches must be installed using the exact procedure described in their instruction sheet. The key to success with three-way wall switches is to identify the wire that was connected to the COMMON terminal of the old manual switches and to following the instructions precisely.
4. Modules that work intermittently from the Model 1050 but reliably locally usually have a problem "hearing" the X-10 signal over the power lines. Some tips:
  - Make sure connections to the modules and to the TW523 interface are tight. Loose fuses, wirenuts, circuit breakers, terminal blocks, corrosion, etc. can sometimes inhibit the X-10 signal.
  - Run a separate wire from the Model 1050 controller directly to the fuse or breaker panel to ensure that the X-10 signal has a clear path to the panel where it can be distributed to the other circuits. Try changing the phase that the system is on.
  - Install a .1 MFD 600 volt non-polarized capacitor between the phase that the powerline interface is on and the other phase(s). BE VERY CAREFUL DURING INSTALLATION. Be sure that the capacitor is on the protected side of the fuses or breakers. This will bridge the signal to the other phases.
  - Items such as electric heaters (resistive loads) and power filters (capacitive loads) tend to absorb the X-10 signal. Try relocating them, if possible.
  - Interference from neighboring systems can be solved by changing the house code to a different one from the neighboring system.
  - Identify any devices that could be transmitting a continuous signal on the powerlines. Wireless Intercoms locked in the transmit mode will prevent X-10 signals from getting out. These are not compatible with X-10.

## **DIGITAL COMMUNICATOR**

The Model 1050 digital communicator uses standard 4/2, (20 pps, 1800 Hz data, 2300 Hz handshake), or (10 pps, 1900 Hz data, 1400 Hz handshake), dual round compared format. Although the alarm codes can be changed, we recommend that the alarm codes setup at the factory be used to minimize the risk of installer error in programming the digital communicator. Simply enter the phone numbers and account codes, then verify the alarm codes.

4/2 format can be received by any central station with modern equipment. Compatible receivers are Ademco, Radionics, Osborne-Hoffman, Linear, FBI, Silent Knight and most others.

### **DESCRIPTION OF 4/2 FORMAT**

The 4/2 format consists of a four-digit account code, from 0000 to FFFF and a two-digit alarm code from 00 to FF. When the digital communicator calls the central station receiver, the latter answers and sends a brief 2300 Hz tone or a 1400 Hz tone called a "Handshake" tone. The digital communicator then reports digits of the account and alarm codes as bursts of either (1800 Hz) or (1900 Hz) tone; the digit 8 is represented by eight bursts of tone. A message, or "round" consists of an account code and an alarm code. Two rounds are sent, and two consecutive rounds must match at the receiver. If they do, the central station receiver sends another brief 2300 Hz or 1400 Hz tone to acknowledge to the digital dialer that the message has been properly received. If the rounds don't match, the receiver does not send the second tone and the digital dialer tries again, up to 5 times. If the rounds are not acknowledged after 5 tries, the digital dialer hangs up and tries the entire call again.

If the digital dialer does not get a handshake signal 45 seconds after it begins dialing, it hangs up and tries again. The dialer will try the FIRST PHONE NUMBER 5 times, then go to the SECOND PHONE NUMBER and try that 5 times. After that, the system will indicate COMMUNICATIONS FAILURE on the keypad display and the digital communicator will not try again until another reportable event occurs.

The FIRST ACCT NUMBER will be used when the central station is called using the FIRST PHONE NUMBER. The SECOND PHONE NUMBER, if specified, will be called if the communicator is unable to successfully communicate using the FIRST PHONE NUMBER/FIRST ACCT NUMBER. The SECOND ACCT NUMBER will be used when the central station is called using the SECOND PHONE NUMBER.

The digital communicator can report alarm zone trips, alarm cancels, low battery, and fire zone trouble. It may also be setup to generate an automatic test signal at periodic intervals. The communicator may be setup to call second phone number using a second account number in the event that it is unable to communicate successfully using the first phone number and account.

The digital communicator is setup at the factory to transmit a code when the battery is low or trouble with the fire zone is detected. If these codes are set to 0 or 00, no code will be sent when the trouble condition is detected.

The digital communicator will not dial out until the DIAL OUT DELAY has expired. If the alarm is canceled prior to the expiration of the DIAL OUT DELAY, no transmission will take place. After the DIAL OUT DELAY has expired, though, all alarm trips will be transmitted followed by a CANCEL code.

When the digital communicator is used, all voice dial outs will be delayed for five minutes after the expiration of the dial out delay to allow time for the central station to call the premises after an alarm code has been sent. If the digital communicator is unable to successfully communicate with the central station, the user will be alerted to the COMMUNICATOR trouble condition. When the system status is requested using the voice, this condition is reported over the phone as "SECURITY PHONE MESSAGE" trouble.

### **3/1 FORMAT**

Older central stations may require a 3/1 format. To use 3/1 format, both account numbers must be changed to 3 digit codes and EVERY alarm code must be changed to a 1-digit code. Do not mix code lengths!

### **OPENING AND CLOSING REPORTS**

The Model 1050 system can send opening and closing reports by user to the central station.

When the system is disarmed by user code 1-16, the communicator can call the central station and report that the system was disarmed (opened) with the user code that was used.

When the system is armed by user code 1-16, the communicator can call the central station and report that the system was armed (closed) with the user code that was used.

If the system is disarmed by any other method other than one that requires a user code (i.e. Keyswitch or Scheduled Program), the communicator will send a generic OPEN report to the central station. The code that is sent is defined as OTHER OPEN.

If the system is armed by any other method other than one that requires a user code (i.e. Quick Arm, Keyswitch, or Scheduled Program), the communicator will send a generic CLOSE report to the central station. The code that is sent is defined as OTHER CLOSE.

## INSTALLER SETUP

This section describes the items that the installer must setup as part of system installation. The Installer Setup mode is used to configure the general operation of the system, the Outputs, the Areas, the Zone Types, and the Digital Communicator. This information is covered only in this manual. All other SETUP items, including delay times, zone and unit names, voice dialer, and codes are covered in the Owner's Manual, Document No. 889152.

SETUP items are stored permanently in the system, even if the battery and AC power are disconnected. The "default" settings are the ones that have been set at the factory. You can review or change the setup items easily, as shown below. If changes have been made from the default settings, it is suggested that they be written in the space provided at the end of this section. **Note:** The default Installer Code is 1111.

To enter the Installer SETUP menu, press 9, and the installer code to get the Setup Menu, then press the # (INST) key.

```
INSTALLER SETUP MENU:
1=CTRL  2=ZONE  3=DCM  ↓
4=AREA  5=TEMP  6=MISC
                                     ↑
```

## SETUP CONTROL

To setup the X-10 and Auxiliary Outputs, from the Installer Setup menu, select the 1 (CTRL) key. The base X-10 house code must be specified, as well as the output type for each of the Auxiliary Outputs. The output type for both the interior and exterior horns may also be changed.

Press (↓) to advance to the next item, (↑) to go back.

### X-10 HOUSE CODE

The base house code is the house code for units 1-16 and is referenced as house code 1. The house code for the units 17-32 is the next house code after the base house code, or house code "B" if the base house code is "A". House codes "C", "D", "E", "F", "G", and "H" will follow for units 33-128.

```
X-10 HOUSE CODE:      A
1-16=A-P              ↓
```

### X-10 3-PHASE

This setting is used to select whether the X-10 signal is transmitted only at zero crossing for single phase (120V/240V) electrical systems or is transmitted at 0, 60, and 120 degrees for three phase electrical systems.

```
X-10 3-PHASE:        0
0=NO 1=YES           ↓
```

To turn 3-Phase On, press 1 then '#'. To turn 3-Phase Off, press 0 then '#'. The burst at 60 and 120 degrees will be eliminated.

The default setting for 3-Phase is No.



## OUTPUT TYPES

An output type must be specified for each of the auxiliary outputs and for the interior and exterior horn outputs. The following output types are available:

OUTPUT TYPE	NUMBER	DESCRIPTION
GENERAL PURPOSE	0	General Purpose Output
OK TO ARM	1	OK To Arm
ARMED	2	Armed
PRE-ALM SNDR	3	Pre-Alarm Sounder
INT SNDR	4	Interior Sounder
INT BURG SNDR	5	Interior Burglary Sounder
INT FIRE SNDR	6	Interior Fire Sounder
EXT SNDR	7	Exterior Sounder
EXT BURG SNDR	8	Exterior Burglary Sounder
EXT FIRE SNDR	9	Exterior Fire Sounder
BURG COMM	10	Burglary Communicator
FIRE COMM	11	Fire Communicator
AUX COMM	12	Auxiliary Communicator
A1 OK TO ARM	17	Area 1 OK To Arm
A1 ARMED	18	Area 1 Armed
A1 PRE-ALM SNDR	19	Area 1 Pre-Alarm Sounder
A1 INT SNDR	20	Area 1 Interior Sounder
A1 INT BURG SNDR	21	Area 1 Interior Burglary Sounder
A1 INT FIRE SNDR	22	Area 1 Interior Fire Sounder
A1 EXT SNDR	23	Area 1 Exterior Sounder
A1 EXT BURG SNDR	24	Area 1 Exterior Burglary Sounder
A1 EXT FIRE SNDR	25	Area 1 Exterior Fire Sounder
A1 BURG COMM	26	Area 1 Burglary Communicator
A1 FIRE COMM	27	Area 1 Fire Communicator
A1 AUX COMM	28	Area 1 Auxiliary Communicator
A2 OK TO ARM	33	Area 2 OK To Arm
A2 ARMED	34	Area 2 Armed
A2 PRE-ALM SNDR	35	Area 2 Pre-Alarm Sounder
A2 INT SNDR	36	Area 2 Interior Sounder
A2 INT BURG SNDR	37	Area 2 Interior Burglary Sounder
A2 INT FIRE SNDR	38	Area 2 Interior Fire Sounder
A2 EXT SNDR	39	Area 2 Exterior Sounder
A2 EXT BURG SNDR	40	Area 2 Exterior Burglary Sounder
A2 EXT FIRE SNDR	41	Area 2 Exterior Fire Sounder
A2 BURG COMM	42	Area 2 Burglary Communicator
A2 FIRE COMM	43	Area 2 Fire Communicator
A2 AUX COMM	44	Area 2 Auxiliary Communicator

A3 OK TO ARM	49	Area 3 OK To Arm
A3 ARMED	50	Area 3 Armed
A3 PRE-ALM SNDR	51	Area 3 Pre-Alarm Sounder
A3 INT SNDR	52	Area 3 Interior Sounder
A3 INT BURG SNDR	53	Area 3 Interior Burglary Sounder
A3 INT FIRE SNDR	54	Area 3 Interior Fire Sounder
A3 EXT SNDR	55	Area 3 Exterior Sounder
A3 EXT BURG SNDR	56	Area 3 Exterior Burglary Sounder
A3 EXT FIRE SNDR	57	Area 3 Exterior Fire Sounder
A3 BURG COMM	58	Area 3 Burglary Communicator
A3 FIRE COMM	59	Area 3 Fire Communicator
A3 AUX COMM	60	Area 3 Auxiliary Communicator
A4 OK TO ARM	65	Area 4 OK To Arm
A4 ARMED	66	Area 4 Armed
A4 PRE-ALM SNDR	67	Area 4 Pre-Alarm Sounder
A4 INT SNDR	68	Area 4 Interior Sounder
A4 INT BURG SNDR	69	Area 4 Interior Burglary Sounder
A4 INT FIRE SNDR	70	Area 4 Interior Fire Sounder
A4 EXT SNDR	71	Area 4 Exterior Sounder
A4 EXT BURG SNDR	72	Area 4 Exterior Burglary Sounder
A4 EXT FIRE SNDR	73	Area 4 Exterior Fire Sounder
A4 BURG COMM	74	Area 4 Burglary Communicator
A4 FIRE COMM	75	Area 4 Fire Communicator
A4 AUX COMM	76	Area 4 Auxiliary Communicator
A5 OK TO ARM	81	Area 5 OK To Arm
A5 ARMED	82	Area 5 Armed
A5 PRE-ALM SNDR	83	Area 5 Pre-Alarm Sounder
A5 INT SNDR	84	Area 5 Interior Sounder
A5 INT BURG SNDR	85	Area 5 Interior Burglary Sounder
A5 INT FIRE SNDR	86	Area 5 Interior Fire Sounder
A5 EXT SNDR	87	Area 5 Exterior Sounder
A5 EXT BURG SNDR	88	Area 5 Exterior Burglary Sounder
A5 EXT FIRE SNDR	89	Area 5 Exterior Fire Sounder
A5 BURG COMM	90	Area 5 Burglary Communicator
A5 FIRE COMM	91	Area 5 Fire Communicator
A5 AUX COMM	92	Area 5 Auxiliary Communicator

A6 OK TO ARM	97	Area 6 OK To Arm
A6 ARMED	98	Area 6 Armed
A6 PRE-ALM SNDR	99	Area 6 Pre-Alarm Sounder
A6 INT SNDR	100	Area 6 Interior Sounder
A6 INT BURG SNDR	101	Area 6 Interior Burglary Sounder
A6 INT FIRE SNDR	102	Area 6 Interior Fire Sounder
A6 EXT SNDR	103	Area 6 Exterior Sounder
A6 EXT BURG SNDR	104	Area 6 Exterior Burglary Sounder
A6 EXT FIRE SNDR	105	Area 6 Exterior Fire Sounder
A6 BURG COMM	106	Area 6 Burglary Communicator
A6 FIRE COMM	107	Area 6 Fire Communicator
A6 AUX COMM	108	Area 6 Auxiliary Communicator
A7 OK TO ARM	113	Area 7 OK To Arm
A7 ARMED	114	Area 7 Armed
A7 PRE-ALM SNDR	115	Area 7 Pre-Alarm Sounder
A7 INT SNDR	116	Area 7 Interior Sounder
A7 INT BURG SNDR	117	Area 7 Interior Burglary Sounder
A7 INT FIRE SNDR	118	Area 7 Interior Fire Sounder
A7 EXT SNDR	119	Area 7 Exterior Sounder
A7 EXT BURG SNDR	120	Area 7 Exterior Burglary Sounder
A7 EXT FIRE SNDR	121	Area 7 Exterior Fire Sounder
A7 BURG COMM	122	Area 7 Burglary Communicator
A7 FIRE COMM	123	Area 7 Fire Communicator
A7 AUX COMM	124	Area 7 Auxiliary Communicator
A8 OK TO ARM	129	Area 8 OK To Arm
A8 ARMED	130	Area 8 Armed
A8 PRE-ALM SNDR	131	Area 8 Pre-Alarm Sounder
A8 INT SNDR	132	Area 8 Interior Sounder
A8 INT BURG SNDR	133	Area 8 Interior Burglary Sounder
A8 INT FIRE SNDR	134	Area 8 Interior Fire Sounder
A8 EXT SNDR	135	Area 8 Exterior Sounder
A8 EXT BURG SNDR	136	Area 8 Exterior Burglary Sounder
A8 EXT FIRE SNDR	137	Area 8 Exterior Fire Sounder
A8 BURG COMM	138	Area 8 Burglary Communicator
A8 FIRE COMM	139	Area 8 Fire Communicator
A8 AUX COMM	140	Area 8 Auxiliary Communicator

The first group of outputs is global. The sounder and communicator outputs will be activated for an alarm in any area. The remaining types are area specific. Area specific sounder and communicator types will only be activated for alarms in that area. The Setup Control items are:

```

X-10 HOUSE CODE:      A
1-16=A-P              ↓

OUTPUT 1 TYPE:        0
GENERAL PURPOSE #=CHNG ↓

OUTPUT 2 TYPE:        0
GENERAL PURPOSE #=CHNG ↓

OUTPUT 3 TYPE:        0
GENERAL PURPOSE #=CHNG ↓

OUTPUT 4 TYPE:        0
GENERAL PURPOSE #=CHNG ↓

OUTPUT 5 TYPE:        0
GENERAL PURPOSE #=CHNG ↓

OUTPUT 6 TYPE:        0
GENERAL PURPOSE #=CHNG ↓

OUTPUT 7 TYPE:        0
GENERAL PURPOSE #=CHNG ↓

OUTPUT 8 TYPE:        0
GENERAL PURPOSE #=CHNG ↓

INTERIOR HORN:        4
INT SNDR              #=CHNG ↓

EXTERIOR HORN:        7
EXT SNDR              #=CHNG ↑

```

For output types, the current setting is shown on the bottom line. Press the '#' key to select a new type from a list of types. The display shows:

```

SELECT TYPE:          6
INT SNDR              ↓

```

Use the Up and Down arrow keys to scroll through the list, or select the appropriate output type number. Then press '#' to enter the new type.

## SETUP ZONES

To setup the zone type for each security zone, from the Installer Setup menu, select the 2 (ZONE) key.

### ZONE EXPANSION

A Hardwire Expander can be used to add 16 zones (zones 17-32) to the Model 1050 system. If used, you must enable the following item:

```
HARDWIRE EXPANDER:      0
0=NO 1=YES              ↓
```

Expansion Enclosures can be used to add up to 64 zones (zones 33-96) to the Model 1050 system. Each Expansion Enclosure adds 16 zones to the system. If used, you must specify the number of enclosures used.

If a Wireless Receiver is being used, you must specify how many groups of zones are being used. Up to 4 groups of 16 zones may be used (zones 33-96).

```
NUMBER OF EXP ENCL     0
1-4                     ↓
```

### Z 1 TYPE THROUGH Z 96 TYPE

This item specifies the zone type for each zone. The possible choices are listed in this manual under DESCRIPTION OF ZONE TYPES.

For zone types, the current setting is shown on the bottom line.

```
ZONE 1 TYPE:           64
AUXILIARY              #=CHNG ↓
```

THROUGH

```
ZONE 96 TYPE:         64
AUXILIARY             #=CHNG ↑
```

To change a zone type, use the arrow keys to scroll through the list of zone types then press '#' to select a new type. The display shows:

```
SELECT TYPE:          1
PERIMETER             ↓
```

### ZONE RESPONSE TIME

All zones, in the Model 1050 are set to 300 milliseconds fixed response time.

## **ZONE TYPES**

<b>ZONE TYPE</b>	<b>NUMBER</b>	<b>DESCRIPTION</b>
ENTRY/EXIT	0	Entry/Exit
PERIMETER	1	Perimeter
NIGHT INT	2	Night Interior
AWAY INT	3	Away Interior
2X ENTRY DELAY	4	Double Entry Delay
4X ENTRY DELAY	5	Quadruple Entry Delay
LATCH PERIM	6	Latching Perimeter
LATCH NIGHT INT	7	Latching Night Interior
LATCH AWAY INT	8	Latching Away Interior
PANIC	16	Panic
POLICE EMERG	17	Police Emergency
SILENT DURESS	18	Duress
TAMPER	19	Tamper
LATCH TAMPER	20	Latching Tamper
FIRE	32	Fire
FIRE EMERG	33	Fire Emergency
GAS	34	Gas Alarm
AUX EMERG	48	Auxiliary Emergency
TROUBLE	49	Trouble
FREEZE	54	Freeze
WATER	55	Water
FIRE TAMPER	56	Fire Tamper
AUXILIARY	64	Auxiliary
KEY SWITCH	65	Keypress Input
OUTDOOR TMP	81	Outdoor Temperature
TEMPERATURE	82	Temperature
TEMP ALARM	83	Temperature Alarm

## **LATCHING ZONE TYPES**

LATCHING ZONE TYPES ignore the status of that zone during power cycles. Used primarily when more than one area is being protected, this type will ignore the status of LATCHING ZONES in that area when the power is switched to devices due to an arming in another area.

If the FIRE ALARM VERIFICATION feature is being used, any device (other than FIRE or GAS) connected to SWITCH 12V (i.e. Glassbreak Detectors) must be connected to a zone configured as a LATCHING ZONE TYPE (latching perimeter, latching night interior, latching away interior, and latching tamper).

## **DESCRIPTION OF ZONE TYPES**

### **ENTRY/EXIT**

ENTRY/EXIT ZONE types are intended for doors. ENTRY/EXIT ZONES are armed in security modes DAY, NIGHT, AWAY, and VACATION. In DAY and AWAY modes, there is an entry delay (defined by ENTRY DELAY) on ENTRY/EXIT ZONES to allow you to get into the house and turn off the alarm before it sounds. In NIGHT & DAY INSTANT mode, there is no entry delay, so that the alarm sounds immediately if someone opens a door.

There are two special types of ENTRY/EXIT ZONES for use with garage doors, or doors that are far away from the control keypad. They are called DOUBLE ENTRY DELAY and QUADRUPLE ENTRY DELAY zones. These zones have double or quadruple the ENTRY DELAY to give you additional time to reach the keypad to disarm the system upon returning. Only the ENTRY DELAY is extended on these zone types. The EXIT DELAY is not extended.

If an ENTRY/EXIT ZONE is tripped first, all other zones will also be delayed.

#### **PERIMETER and LATCHING PERIMETER**

PERIMETER ZONE types are intended for windows and exterior doors not requiring an entry delay. All PERIMETER ZONES are armed in security modes DAY, NIGHT, AWAY, and VACATION. There is not an entry delay on a perimeter zones. If a window or door on this zone is opened while the security system is in DAY, NIGHT, AWAY or VACATION mode, the alarm will sound immediately.

LATCHING PERIMETER ZONES ignore the status of that zone during power cycles.

#### **NIGHT INTERIOR and LATCHING NIGHT INTERIOR**

NIGHT INTERIOR ZONES are intended for motion detectors in areas where no one should be while you are sleeping in your home. For example, if you have a two story home and sleep upstairs, your downstairs motion detector(s) should be on a NIGHT INTERIOR ZONE.

NIGHT INTERIOR ZONES are armed in security modes NIGHT, VACATION, and AWAY only. There is no delay on a NIGHT INTERIOR ZONE. Night interior zones are NOT armed in DAY or DAY INSTANT mode, so that you may move about freely in your home when the security system is in DAY or DAY INSTANT mode, while still having the windows and doors protected.

LATCHING NIGHT INTERIOR ZONES ignore the status of that zone during power cycles.

#### **AWAY INTERIOR and LATCHING AWAY INTERIOR**

AWAY INTERIOR ZONES are for all other areas of your home, where no one should be while you are away. In the previous example, your upstairs motion detector(s) should be on an AWAY INTERIOR ZONE. AWAY INTERIOR ZONES are armed only when the security mode is AWAY.

LATCHING AWAY INTERIOR ZONES ignore the status of that zone during power cycles.

#### **PANIC, TAMPER, and LATCHING TAMPER**

PANIC and TAMPER ZONES are for emergency pushbuttons and tamper switches. PANIC and TAMPER ZONES are ALWAYS ARMED, even if the security mode is OFF. There are no delays on PANIC and TAMPER ZONES, however, the Model 1050 waits the DIAL OUT DELAY before dialing out.

TAMPER ZONES should be used for items such as gun cabinets and liquor closets.

LATCHING TAMPER ZONES ignore the status of that zone during power cycles.

#### **POLICE EMERGENCY**

This zone type activates the burglar alarm and makes an emergency dial out. The interior and exterior sounders are activated immediately. There is a delay before dialing out.

## **DURESS EMERGENCY (SILENT DIAL OUT)**

If you wish to have a button in your home that activates a SILENT dial out, that is, one with no lights flashing, no interior sounder and no exterior sounder, that button should be connected to a zone, and the zone type for that zone should be changed to DURESS EMERGENCY. Use caution in assigning a zone type to DURESS EMERGENCY. If this zone is accidentally tripped, you will not know that the Model 1050 is making a silent dial out, and hence won't know to stop it if it was a mistake.

To stop a silent dial out once it has started, you must go to the keypad and press OFF then enter your user code number.

## **SUPERVISED FIRE**

Any zone in the Model 1050 can be programmed as a SUPERVISED FIRE ZONE. In UL Listed Installations, any fire zone must be supervised and connected as shown in this manual.

## **FIRE EMERGENCY**

This zone type activates the fire alarm for a NORMALLY CLOSED, OPEN FOR ALARM loop. It is not supervised as required for UL Listed Installations and shall NOT be used in such installations.

## **GAS**

This GAS ALARM will generate an alarm, activate interior and exterior sounders (on - off - on - long off), and make a dial out.

## **AUXILIARY EMERGENCY**

This AUXILIARY EMERGENCY ALARM ZONE type will generate an alarm (keypad beeper, no sirens) and make an emergency dial out when the zone is violated.

## **TROUBLE**

This zone type can be used to monitor the status of an external device, such as the battery status of a wireless security receiver. When the zone is open, the zone name will be displayed on the display as "NOT RDY". The alarm is not activated, regardless of the security mode.

The trouble is logged in the event log. The digital communicator (if used) will report the alarm code for the zone. The voice dialer will not be activated. This zone type can be used to record events in the event log - driveway activation, opening of a gate, outdoor motion, etc. without setting off the alarm. If the digital communicator is programmed for other alarms, this zone can be excluded by programming the alarm code for this zone to 0.

## **FREEZE**

This FREEZE ALARM ZONE type will generate an alarm (keypad beeper, no sirens) and make an emergency dial out when the zone is violated.

## **WATER**

This WATER ALARM ZONE type will generate an alarm (keypad beeper, no sirens) and make an emergency dial out when the zone is violated.



## **FIRE TAMPER**

This zone type is used to monitor the wiring to bells and sirens. The zone will report trouble if an open, short, or other wiring problem is detected in the supervised bell circuit. This zone will make a digital dial out when violated. In UL Listed Installations, each fire siren must be supervised by a fire tamper zone connected as shown in this manual. **Note:** Only Zones 1-8 can be configured as FIRE TAMPER zones.

## **AUXILIARY INPUT**

A zone defined as an AUXILIARY INPUT is ignored by the security part of the system. It is used to activate "button" commands or to conditionalize programs.

## **KEYSWITCH INPUT**

This zone is used to arm in AWAY and disarm the Model 1050 security system using an ARM/DISARM TOGGLE (to ground) keyswitch or keypad.

## **OUTDOOR TEMPERATURE**

Use this zone type for Outdoor Temperature Sensors.

## **TEMPERATURE**

The general-purpose TEMPERATURE ZONE type is typically used to monitor indoor temperatures and control devices. It sets the zone secure/not ready for program conditionals and event button activation.

If FREEZE ALARM is enabled, it reports a potential freeze condition if the temperature falls below 40°.

## **TEMPERATURE ALARM**

The TEMPERATURE ALARM ZONE type will generate an alarm (keypad beeper, no sirens) and dial out if the temperature goes above the high setpoint or drops below the low setpoint.

## **NOTE ON TEMPERATURE ZONE TYPES**

Outdoor temperature, temperature, and temperature alarm zone types all have HEAT and COOL setpoints. The zone is "not ready" if the temperature is above the high setpoint OR below the low setpoint. The zone is "secure" if the temperature is between the setpoints. Setting a setpoint to 0 disables the setpoint.

Except for a type 83, the alarm is not activated. The zone "not ready" or "secure" status is used to activate button programs and program conditionals.

## SETUP DIGITAL COMMUNICATOR

To setup the Digital Communicator, from the Installer Setup menu, select the 3 (DCM) key.

### FIRST PHONE NUMBER, FIRST ACCOUNT NUMBER

The first item in the DIGITAL COMMUNICATOR category is the FIRST PHONE NUMBER. Enter the FIRST PHONE NUMBER on the keypad. This enables the Digital Communicator. You can cause a 2-second pause during dialing by pressing the DAY key. Press '#' when done.

```
FIRST PHONE NUMBER:
-                               ↓
```

To disable the digital communicator, enter a single "-" for the FIRST and SECOND PHONE NUMBER by pressing the OFF key, then '#'. Phone number may be up to 24 digits long.

Press the down arrow (↓) to advance to the FIRST ACCT NUMBER:

```
FIRST ACCT NUMBER:  0000
0-FFFF              ↓
```

Enter the 4 digit account number (3 digits if using 3/1 format) and press '#'. To enter the digits B-F, first press the OFF key, then press the 1-5 key respectively (i.e. 1B11 = 1 OFF 1 1 1 #).

NOTE: You must enter 4 digits for the account number if you are using 4/2 format (i.e. 0123), and 3 digits if using 3/1 (i.e. 123).

### SECOND PHONE NUMBER, SECOND ACCOUNT NUMBER

Enter these if used.

```
SECOND PHONE NUMBER:
-                               ↓

SECOND ACCT NUMBER:  0000
0-9999              ↓
```

### COMMUNICATOR TYPE

The Model 1050 can transmit in both FAST 2300 Hz (20 PPS) mode, or in SLOW 1400 Hz (10 PPS) 3/1 format.

```
COMMUNICATOR TYPE:    0
0=2300 1=1400         ↓
```

The default setting is 0 = 2300 Hz. If you need to transmit to a 1400 Hz receiver, press 1 then '#'.

### TWO-WAY AUDIO

If a Two-Way Audio Module is being used, this item enables hands free audio communication between your customer's premises and the central station. After the transmission of the alarm to the central station, the operator can talk and listen to people and sounds at the premises.

TWO-WAY AUDIO: 0  
0=NO 1=YES ↓

If a Two-Way Audio Module is part of the system, select the 1 (YES) key to enable this feature.

### REPORT OPEN/CLOSE

The communicator can be setup to send an opening and a closing report by user code. Whenever the system is disarmed the communicator will send an opening report to the central station. When the system is armed, the communicator will send a closing report to the central station.

REPORT OPEN/CLOSE: 0  
0=NO 1=YES ↓

To enable the communicator to send opening and closing reports to the central station, select the 1 (YES) key.

### AUTOMATIC TEST TIME

The communicator CAN be setup to automatically send a test code to the central station on a periodic basis. AUTOMATIC TEST TIME is used to set the time and days of the week of the test, and the TEST CODE specifies the code that will be transmitted for the test.

AUTOMATIC TEST TIME:  
-- NEVER #=CHNG↑

To disable the automatic test, press the '#' key and then 0 for Never, and '#'.

TEST CODE: 98  
0-FF ↓

### ALARM CODES

Press the down arrow (↓) to advance to the next ZONE ALARM CODE. Press the up arrow (↑) to go to the previous ZONE ALARM CODE. To change an alarm code, enter two digits for 4/2 format, or one digit when using 3/1 format, then press the '#' key.

Enter the 2 digit alarm code (1 digit if using 3/1 format) and press '#'. To enter the digits B-F, first press the OFF key, then press the 1-5 key respectively (i.e. B1 = OFF 1 1 # and CB = OFF 2 OFF 1 #).

The various alarm codes are sent when the indicated alarm zone is tripped. Each alarm code must be two digits long for 4/2 format (01-FF), 1 digit for 3/1 format (1-F).

To disable the digital communicator for a specific zone, set the alarm code to 0 or 00. The digital dialer will not report when this zone is tripped.

ZONE 1 ALARM CODE: 01  
0-FF ↓

### THROUGH

USER 16 CLOSE CODE: 76  
0-FF ↑

## SETUP AREAS

To configure the system for multiple areas, from the Installer Setup menu, press the 4 (AREA) key. The number of areas must be specified. Also, keypads, zones, units, thermostats, and buttons must be assigned to areas. By default, the system is setup for one area.

The display prompts for the number of areas that will be used:

```
NUMBER OF AREAS:      1
1-8
```

If you choose 2, the Setup Areas menu is displayed:

```
SETUP AREAS
1=CTRL  2=ZONES  3=BTTN ↓
4=CONS  5=TEMP   8=MSG
                                     ↑
```

## SETUP AREAS: CONTROL

To assign control units to specific areas, from the Setup Areas menu, press the 1 (CTRL) key.

Units can be setup so that they can be activated from specific areas or from all areas.

Units for an entire X-10 house code can be assigned to specific areas. Units 129-192 may be assigned individually to specified areas.

```
UNITS 1-16 AREAS:
1 2 3 4 5 6 7 8  0=CLR ↓
```

```
UNITS 17-32 AREAS:
1 2 3 4 5 6 7 8  0=CLR ↓
```

```
UNITS 33-48 AREAS:
1 2 3 4 5 6 7 8  0=CLR ↓
```

```
UNITS 49-64 AREAS:
1 2 3 4 5 6 7 8  0=CLR ↓
```

```
UNITS 65-80 AREAS:
1 2 3 4 5 6 7 8  0=CLR ↓
```

```
UNITS 81-96 AREAS:
1 2 3 4 5 6 7 8  0=CLR ↓
```

```
UNITS 97-112 AREAS:
1 2 3 4 5 6 7 8  0=CLR ↓
```

```
UNITS 113-128 AREAS:
1 2 3 4 5 6 7 8  0=CLR ↓
```

```
UNITS 129-132 AREAS:
1 2 3 4 5 6 7 8  0=CLR ↓
```

UNITS 133-136 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 137-140 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 141-144 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 145-148 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 149-152 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 153-156 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 157-160 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 161-164 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 165-168 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 169-172 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 173-176 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 177-180 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 181-184 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 185-188 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 189-192 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 193 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 194 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 195 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 196 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓

```

UNITS 197 AREAS:
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 198 AREAS:
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 199 AREAS:
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 200 AREAS:
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 201-208 AREAS:
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 209-216 AREAS:
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 217-224 AREAS:
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 225-232 AREAS:
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 233-240 AREAS:
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 241-248 AREAS:
1 2 3 4 5 6 7 8 0=CLR ↓

UNITS 249-255 AREAS:
1 2 3 4 5 6 7 8 0=CLR ↑

```

**SETUP AREAS: ZONES**

To assign zones to areas, from the Setup Areas menu, press 2 (ZONE). Each zone must be assigned to one and only one area.

```

ZONE 1 AREA:          1
1-8                   ↓

```

THROUGH

```

ZONE 96 AREA         1
1-8                   ↑

```

## SETUP AREAS: BUTTONS

To assign groups of macro buttons to specific areas, from the Setup Areas menu, press the 3 (BTTN) key.

Buttons can be setup so that they can only be activated from a particular area or from any area. Buttons are assigned to areas in groups of eight.

```
BUTTONS 1-8 AREAS:
1 2                0=CLR ↓

BUTTONS 9-16 AREAS:
1 2                0=CLR ↓

BUTTONS 17-24 AREAS:
1 2                0=CLR ↓

BUTTONS 25-32 AREAS:
1 2                0=CLR ↓

BUTTONS 33-40 AREAS:
1 2                0=CLR ↓

BUTTONS 41-48 AREAS:
1 2                0=CLR ↓

BUTTONS 49-56 AREAS:
1 2                0=CLR ↓

BUTTONS 57-64 AREAS:
1 2                0=CLR ↑
```

## SETUP AREAS: KEYPADS

To assign keypads to areas, from the Setup Areas menu, press the 4 (CONS) key.

Each keypad must be assigned to one and only one area. A keypad may be set to global, which allows it to access areas other than its assigned area through security arming and the "go to" function.

```
CONSOLE 1 AREA:      1
1-8                  ↓

CONSOLE 1 GLOBAL:    1
0=NO 1=YES          ↓
```

THROUGH

```
CONSOLE 16 AREA:     1
1-8                  ↓

CONSOLE 16 GLOBAL:   1
0=NO 1=YES          ↑
```

## SET-UP AREAS: THERMOSTATS

To assign thermostats to specific areas, from the Set-up Areas menu, press the 5 (TEMP) key.

Thermostats can be set up so that they can only be controlled from a specific area or from all areas. Temperature Sensors can only be controlled from a single area, as specified in SET-UP AREAS.

```
THERMOSTAT 1 AREAS:  
1 2          0=CLR ↓
```

THROUGH

```
THERMOSTAT 64 AREAS:  
1 2          0=CLR ↑
```

## SETUP AREAS: MESSAGES

To assign messages to specific areas, from the Setup Areas menu, press the 8 (MSG) key.

Messages can be setup so that they can be displayed in a specific area or in all areas.

```
MESSAGES 1-8 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓
```

```
MESSAGES 9-16 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓
```

```
MESSAGES 17-24 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓
```

```
MESSAGES 25-32 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓
```

```
MESSAGES 33-40 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓
```

```
MESSAGES 41-48 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓
```

```
MESSAGES 49-56 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↓
```

```
MESSAGES 57-64 AREAS:  
1 2 3 4 5 6 7 8 0=CLR ↑
```



## SETUP TEMPERATURES

To configure temperatures from the Installer Setup Menu, press the 5 (Temp) key.

### TEMPERATURE DISPLAY

This allows you to choose between Fahrenheit or Celsius temperature format.

```
TEMPERATURE DISPLAY:  1
1=FAHRENHEIT 2=CELSIUS ↓
```

### THERMOSTAT TYPE

If thermostats are part of the system, this item specifies the thermostat type for each thermostat. If thermostats are used, they must be configured to the applicable thermostat type.

For thermostat types, the current setting is shown on the bottom line.

```
THERMOSTAT 1 TYPE:    0
NOT USED              #=CHNG ↓
```

### THROUGH

```
THERMOSTAT 64 TYPE:   0
NOT USED              #=CHNG ↑
```

To enable or change a thermostat type, press the '#' key. Use the arrow keys to scroll through the list of thermostat types, then press '#' to select a new type. The display shows:

```
SELECT TYPE:          1
AUTO HEAT/COOL       ↓
```

TYPE	NUMBER	DESCRIPTION
AUTO HEAT/COOL	1	Automatic changeover heat and cool thermostat
HEAT/COOL	2	Manual changeover heat and cool thermostat
HEAT ONLY	3	Heating only thermostat
COOL ONLY	4	Cooling only thermostat
SETPOINT ONLY	5	Setpoint only thermostat

## SETUP MISCELLANEOUS

To configure the miscellaneous installer setup items, from the Installer Setup menu, press the 6 (MISC) key.

### INSTALLER CODE

The Installer code allows the installer access to the Installer Setup menu. The Installer code should be changed and not given to the customer.

INSTALLER CODE :  
0000-9999 0000=DISABLE↓

The default setting for the Installer code is 1 1 1 1.

#### NOTE:

Remember this Installer code. There is no way to reset or retrieve the code! If the code is forgotten or disabled, the Model 1050 controller must be sent back to the factory. Call for an RA#.

### ENABLE PC ACCESS

This enables or disables the PC ACCESS feature. Set to 0 to disable PC ACCESS, set to 1 to enable PC ACCESS. Factory default is enabled.

ENABLE PC ACCESS :            1  
0=NO 1=YES                    ↓↑

### PC ACCESS CODE

This code allows dealers to put an access code in the system that is separate from the customer's Master code and the Installer code. Dealers can use the PC Access code to access the system by PC. The PC Access code cannot arm and disarm the system. The PC Access code is NOT programmed from the factory. To use it, set any code other than 0000 in PC Access code. To disable the PC Access code, enter 0000 for the code.

NOTE: This item must be enabled (by entering a code) if PC Access is will be used.

PC ACCESS CODE :  
0000-9999 0000=DISABLE↑↓

### CALL BACK PHONE NUMBER

In response to a request for remote PC ACCESS using the PC ACCESS code, the system will hang up and dial this number back immediately. To program the CALLBACK PHONE NUMBER, enter the number then press '#'. To remove the CALLBACK PHONE NUMBER, press the OFF key to enter a single "-", then press '#'.

CALL BACK PHONE NUMBER :  
-                                    ↓

## OUTSIDE SIREN DELAY

When the alarm is "tripped" (activated by a burglar or fire) the interior sounder will sound first, then the outside siren will sound after the OUTSIDE SIREN DELAY. This feature helps reduce annoying false alarms by signaling inside the premises first.

The outside siren delay is set to 15 seconds at the factory. You may change it to any value from 0 to 60 seconds. If you want the outside siren to sound immediately when the alarm is activated, set the delay to zero. We recommend a minimum time of 15 seconds.

To change the OUTSIDE SIREN DELAY, press the desired outside siren delay in seconds, then press the '#' key.

```
DIAL OUT DELAY:      15
0-60 SECONDS        ↓
```

## DIAL OUT DELAY

The DIAL OUT DELAY is the number of seconds that the Model 1050 waits before making an emergency dial out, AFTER the alarm is "tripped" (activated by burglar or fire).

This delay is set at the factory to 15 seconds. We recommend a minimum time of 15 seconds to preclude an accidental activation of the alarm from calling in a false alarm.

To set the dial out delay, enter the desired dial out delay in seconds, then press the '#' key.

```
DIAL OUT DELAY:      15
0-60 SECONDS        ↓
```

## ALARM RESET TIME

The Alarm Reset Time is the time it takes before the alarm system resets itself after the outside siren is activated due to a security violation.

```
ALARM RESET TIME:    4
1-30 MINUTES         ↓
```

To change the alarm reset time, enter a new time between 1-30 minutes, then press the '#' key. The default setting is 4 minutes.

## ARMING CONFIRMATION

The Arming Confirmation is a quick pulse (squawk) given by the outside siren when the alarm system is armed into a security mode and the EXIT DELAY is expired.

```
ARMING CONFIRMATION:  0
0=NO  1=YES           ↓
```

To enable the arming confirmation feature, press the 1 (YES) key, then press the '#' key. The default setting is 0 (NO) disabled.

**FIRE ALARM VERIFICATION**

This unit is equipped with a FIRE ALARM VERIFICATION feature. When a zone configured as a FIRE (Type 32) or a GAS (Type 34) is activated, the system will cycle the SWITCH 12V power output off for 10 seconds. The SWITCH 12V power output will then be restored, and 5 seconds later, the zones will be monitored again. If the zone is activated again within a 2-minute window, the fire alarm will be activated. If not, no fire alarm will be indicated.

VERIFY FIRE ALARMS:        1  
 0=NO 1=YES                    ↓

NOTE:

If VERIFY FIRE ALARMS is turned ON, **any** device (other than FIRE or GAS) connected to SWITCH 12V (i.e. Glassbreak Detectors) must be connected to a zone configured as a LATCHING ZONE TYPE.

This feature is designed to reduce false alarms and is turned ON by factory default. To turn it OFF, set VERIFY FIRE ALARMS to NO.

The following notice is required by UL:

**WARNING**

This unit includes an alarm verification feature that will result in a delay of the system fire alarm signal from the initiating circuit. The total delay (Model 1050 controller plus detector delay) shall not exceed 60 seconds. No other initiating devices shall be connected to these circuits unless approved by the local authority having jurisdiction.

Zone Circuit	Control Unit Delay	Detector Delay	Total Delay
_____	: 10 seconds	+ _____	= _____
_____	: 10 seconds	+ _____	= _____
_____	: 10 seconds	+ _____	= _____
_____	: 10 seconds	+ _____	= _____

**ENABLE EMERGENCY KEYS**

This enables or disables the emergency keys on the keypad to be functional. Select the 1 (YES) key to enable the emergency keys. Select the 2 (NO) key to disable the emergency keys. Factory default is enabled.

ENABLE EMERG KEYS:        1  
 0=NO 1=YES                    ↓

## TIME DISPLAY

This allows you to choose between AM/PM or 24 HOUR time format.

TIME DISPLAY: 1  
1=AM/PM 2=24HR ↓

## DATE DISPLAY

This allows you to choose between MONTH/DAY or DAY/MONTH date format.

DATE DISPLAY: 1  
1=MMDD 2=DDMM ↓

## AC POWER FREQUENCY

Set this to the appropriate frequency.

AC POWER FREQUENCY: 1  
1=60HZ 2=50HZ ↓

## DEAD LINE DETECT

NOTE: Adjust only under direction of OnQ Technologies, Inc.

This item adjusts the threshold that is used to determine when the phone line goes dead.

DEAD LINE DETECT: 8  
0-15 0=DISABLE ↓

## OFF HOOK DETECT

NOTE: Adjust only under direction of OnQ Technologies, Inc.

This item adjusts the threshold that is used to determine when the phone line is going off hook.

OFF HOOK DETECT: 69  
20-250 ↓

## PICKUP AFTER HANGUP

This item is used to disable Model 1050 from picking up the phone line after the called party hangs up the line.

PICKUP AFTER HANGUP: 1  
0=NO 1=YES ↓

Currently, after the called party or the called party's answering machine hangs up the phone line, Model 1050 picks up the line and make its "Beep". If you wish to turn the Pickup After Hangup OFF, press 0 then '#'. To turn it back On, press 1 then '#'.  
The default setting for Pickup After Hangup is Yes.

## CLOCK ADJUSTMENT

If the clock on a Model 1050 is running faster or slower than the actual time, you can have the Model 1050 automatically compensate up to 29 seconds per day. The Model 1050 will add or subtract the selected amount of time daily.

```
CLOCK ADJUSTMENT:      30
1-59=-29 TO +29 SEC/DAY↑
```

Enter 1-29 to subtract 1-29 seconds. Enter 31-59 to add 1-29 seconds. Enter 30 for no adjustment to the clock.

The default setting is 30.

## MODEL AND SOFTWARE VERSION

Next, the model number and software version for the system is displayed:

```
HMS MODEL 1050
S/W VERSION 1.8      ↓
```

## RESET SYSTEM EEPROM

Select the 1 (YES) key to reset the EEPROM. All programs, names, and setup items will be reset. All system RAM will also be initialized and the system will restart. This option, if effect, allows the system to be restored to factory fresh configuration.

```
RESET SYSTEM EEPROM?  0
0=NO  1=YES           ↓
```

## RESET SYSTEM RAM

Select the 1 (YES) key to cause all of the system RAM to be reinitialized. The time, date, and event log will be cleared. Other volatile memory locations will also be reinitialized. The system RAM should only be reset if the system is acting strangely and memory corruption is suspected. Resetting the system RAM will not reset any setup items stored in EEPROM.

```
RESET SYSTEM RAM?    0
0=NO  1=YES          ↑
```

## SETUP EXPANSION

To configure each expansion module that is installed on a system, from the Installer Setup menu, press the 7 (EXP) key.

### MODULE 1 TYPE

The Module Type defines the function of each expansion module on the controller. Module 1 is the module with the ADDR jumper set to 1. Set the module type from the list below. Press # to change the module type, then use the arrow keys to select the proper module type, then press # to enter.

```
MODULE 1 TYPE          1
HARDWIRE EXPNDR  #=CHNG ↓
```

Select from the following for the module with jumper set to 1:

MODULE TYPES	NUMBER	DESCRIPTION
NOT USED	0	No module is installed
HARDWIRE EXPNDR	1	363436-1 Hardwire Expander Module installed
ALC LIGHTING	2	363440-1 or -2 ALC Interface Module installed
HMS-LINK	3	363737-1 Serial Interface using the HMS-Link protocol
PRO-LINK	4	363737-1 Serial Interface using the Pro-Link protocol

Model 1050 supports two Serial Interface Modules. Both Modules can be set to HMS-Link or to Pro-Link. You can also use a combination of HMS-Link and Pro-Link.

### MODULE 2 TYPE - MODULE 4 TYPE

Module 2 is the module with the jumper set to 2, and so on. Set each module type from the list above.

### SERIAL 1 RATE

Select the baud rate for the first serial interface from the list below. Use the arrow keys to select the baud rate then press #.

BAUD RATE	NUMBER
75 baud	1
150 baud	2
300 baud	3
600 baud	4
1200 baud	5
2400 baud	6
4800 baud	7
9600 baud	8 (default)

### SERIAL 2 RATE

If a second serial interface is installed, select its baud rate as shown above.

## MODEL 1050 SPECIFICATIONS

Size: Controller: 13 W x 13 H x 4.5 D  
Keypad: 4.6 W x 4.5 H x 1.2 D

Weight: Controller: approx. 10 lb.  
Keypad: approx. 0.5 lb.

Operating Ranges: 32 - 122 degrees F (0 - 50 degrees C)  
10 - 95 % relative humidity, non-condensing

Power: 120 VAC, 60 Hz, 60 watts

Transformer: 24 VAC, 1.67 amps, 40 VA

Battery: Rechargeable gel-cell, 12 volts, 7 amp-hour

Main Fuse: On Controller: Type 3 AG, 2 A fast blow

Battery Fuse: On Controller: Type 3 AG, 5 A fast blow

Device Fuse: Polyfuse: 1.35 A

Horns Fuse: Polyfuse: 1.35 A

Polyfuses are permanent fuses that do not need replacement.

Nominal Voltage: 10 - 13.7 VDC, 0.5 V max. peak to peak ripple

Low Voltage Cut Out: approx. 9 VDC

Typical Current Consumption at Nominal Voltage:

Controller: 275 mA  
Keypad: backlight off, 35 mA  
backlight on, 100 mA

Controller Maximum Group Current Outputs:

Devices: AUX 12 VDC, SWITCH 12 VDC,  
KEYPAD, and OUTPUTS 1 - 8: 1 A

Horn: INT HORN and EXT HORN: 1 A

Controller Maximum Individual Current Outputs:

Devices: **(Do not exceed 1 A total)**

AUX 12 VDC	1 A
SWITCH 12 VDC	1 A
KEYPAD	1 A
OUTPUTS 1 - 8	100 mA

MINIMUM Battery Backup Time: 4 hours/24 hours (See Figure 10)



# UNDERWRITER'S LABORATORIES (UL) INSTALLATION REQUIREMENTS

The Model 1050 control unit 363432-01 is suitable for Grade A household burglar and fire applications. Refer to UL1641 for installation requirements. Refer to UL 681 for Installation Requirements.

1. The line carrier (X-10) operation is considered supplementary. Operation of the line carrier devices was not investigated by UL.
2. For those zones programmed as PANIC, DURESS or POLICE EMERGENCY, the initiating device shall be a UL Listed Hold Up Device switch.
3. Connections to phone circuit must be made via the supplied cable and RJ31X Jack as shown under RJ31X JACK CONNECTIONS in this manual.
4. For connection of smoke detectors to the controller, refer to requirements under FIRE ZONE HOOKUP and FIRE ZONE CONNECTIONS diagrams in this manual.
5. The controller must be configured for 24 hour Standby Time as shown under 24 HR STANDBY CONNECTIONS diagram in this manual. Maximum current ratings for 24 hours must be observed.
6. Recognized energy limited cable shall be employed, 22 AWG minimum for all connections.
7. The audible signal appliance shall be the Listed Wheelock Model 34T-12 Fire Horn, rated 9 - 15.6 VDC, 85 dB(A) with 2 reflecting planes. This horn shall be connected to a supervisory zone as shown in Figure 6. The zone shall be configured as a FIRE TAMPER zone type. The audible signal shall be mounted indoors in a central location. The audible signal appliance can be connected to either the "HORNS-INT" or "HORNS-EXT" circuits. In the case of the latter, the OUTSIDE SIREN DELAY shall be set to 0 seconds.
8. For Commercial Applications, Listed Ademco AB12 Bell and housing to be used.
9. If the remote arm/disarm switch is used, it shall be the Listed Ademco Model 9789.
10. Refer to the Model 1050 Owner's Manual (Document No. 889152) for programming requirements in UL Listed Installations.
11. For the monitoring of burglar alarm initiating devices, the zone type shall provide an audible output (i.e., not DURESS).
12. The Model 1050 controller must be connected (when employed) to listed gas detectors.
13. All connections to energy sensors and modules must be done to listed Class 2 circuits only.
14. The Model 1050 must be used in Residential Applications that are under a single ownership.


When used in UL Listed Installations, the following items apply:

1. The "High Security Mode" must be ON.
2. The "Enable Auto Bypass" feature must be OFF.
3. The ENTRY DELAY SHALL NOT EXCEED 45 SECONDS for Residential Applications; 60 seconds for Commercial Applications.
4. The EXIT DELAY shall not exceed 60 seconds.
5. Double Delay and Quad Delay zone types shall not be used.
6. For Residential Applications the sounding device may be mounted indoors. If, however, the sounding device is connected to the "EXT HORN" terminals of the Model 1050, then the OUTSIDE SIREN DELAY shall be set to 0.
7. The BEEP ON TROUBLE feature must be ON.
8. Installer: NAME: \_\_\_\_\_ NUMBER: \_\_\_\_\_




# SMOKE DETECTOR INSTALLATION GUIDELINES

1. Ceiling mounted smoke detectors should be located in the center of the room or hall, or not less than 4 inches from any wall. When the detector is mounted on a wall, the top of the detector should be 4 to 12 inches from the ceiling.
2. Do not install smoke detectors where normal ambient temperatures are above 100 deg. F (37.8 deg. C) or below 40 deg. F (4 deg. C). Also, do not locate the detector in front of air conditioners, heating registers, or other locations where normal air circulation will keep smoke from entering the detector.
3. Additional information on Household Fire Warning is available at nominal cost from: The National Fire Protection Association, Battery March Park, Quincy, MA. 02269. Request Standard No. NFPA 72. Contact your home Insurance Company for a possible reduction of your insurance premium.
4. A smoke detector should be located between the sleeping area and the rest of the family living unit.
5. In family living units with more than one sleeping area, a smoke detector should be provided to protect each sleeping area.
6. A smoke detector should be located on each story (Refer to the diagrams below).
7. For complete details on proper location and installation of smoke detectors, refer to the instructions supplied with the smoke detector.




(a) A smoke detector should be located between the sleeping area and the rest of the family living unit.


(b) Where to Locate the Required Smoke Detectors in New Construction. All of the smoke detectors specified in (a) for existing construction are required, and, in addition, a smoke detector is required in each bedroom.



(b) In family living units with more than one sleeping area, a smoke detector should be provided to protect each sleeping area in addition to detectors required in bedrooms.



Split level arrangement. Smoke detectors are required where shown. Smoke detectors are optional if door is not provided between living and recreation rooms.



A smoke detector should be located on each story.

## MODEL 1050 INSTALLATION PLANNER / CHECKLIST

ZONE 1 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 2 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 3 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 4 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 5 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 6 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 7 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 8 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 9 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 10 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 11 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 12 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 13 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 14 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 15 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 16 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

**ZONE EXPANSION:**

HARDWIRE EXPANDER: \_\_\_\_\_

ZONE 17 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 18 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 19 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 20 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 21 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 22 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 23 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 24 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 25 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 26 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 27 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 28 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 29 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 30 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 31 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 32 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

**ZONE EXPANSION:**

HARDWIRE EXPANDER: \_\_\_\_\_ WIRELESS RECEIVER: \_\_\_\_\_

ZONE 33 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 34 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 35 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 36 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 37 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 38 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 39 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 40 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 41 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 42 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 43 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 44 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 45 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 46 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 47 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 48 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_



**ZONE EXPANSION:**

HARDWIRE EXPANDER: \_\_\_\_\_ WIRELESS RECEIVER: \_\_\_\_\_

ZONE 49 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 50 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 51 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 52 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 53 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 54 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 55 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 56 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 57 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 58 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 59 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 60 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 61 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 62 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 63 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 64 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

**ZONE EXPANSION:**

HARDWIRE EXPANDER: \_\_\_\_\_ WIRELESS RECEIVER: \_\_\_\_\_

ZONE 65 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 66 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 67 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 68 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 69 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 70 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 71 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 72 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 73 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 74 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 75 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 76 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 77 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 78 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 79 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 80 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

**ZONE EXPANSION:**

HARDWIRE EXPANDER: \_\_\_\_\_ WIRELESS RECEIVER: \_\_\_\_\_

ZONE 81 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 82 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 83 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 84 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 85 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 86 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 87 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 88 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 89 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 90 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 91 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 92 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 93 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 94 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 95 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

ZONE 96 NAME: \_\_\_\_\_ TYPE: \_\_\_\_\_ AREA: \_\_\_\_\_

VOICE: \_\_\_\_\_ LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

**INTERIOR SOUNDER:**

LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

**OUTDOOR SIREN:**

LOCATION: \_\_\_\_\_ TESTED: \_\_\_\_\_

**KEYPAD 1:**

LOCATION: \_\_\_\_\_ AREA: \_\_\_\_\_ TESTED: \_\_\_\_\_

**KEYPAD 2:**

LOCATION: \_\_\_\_\_ AREA: \_\_\_\_\_ TESTED: \_\_\_\_\_

**KEYPAD 3:**

LOCATION: \_\_\_\_\_ AREA: \_\_\_\_\_ TESTED: \_\_\_\_\_

**KEYPAD 4:**

LOCATION: \_\_\_\_\_ AREA: \_\_\_\_\_ TESTED: \_\_\_\_\_

**KEYPAD 5:**

LOCATION: \_\_\_\_\_ AREA: \_\_\_\_\_ TESTED: \_\_\_\_\_

**KEYPAD 6:**

LOCATION: \_\_\_\_\_ AREA: \_\_\_\_\_ TESTED: \_\_\_\_\_

**KEYPAD 7:**

LOCATION: \_\_\_\_\_ AREA: \_\_\_\_\_ TESTED: \_\_\_\_\_

**KEYPAD 8:**

LOCATION: \_\_\_\_\_ AREA: \_\_\_\_\_ TESTED: \_\_\_\_\_

**KEYPAD 9:**

LOCATION: \_\_\_\_\_ AREA: \_\_\_\_\_ TESTED: \_\_\_\_\_

**KEYPAD 10:**

LOCATION: \_\_\_\_\_ AREA: \_\_\_\_\_ TESTED: \_\_\_\_\_

**KEYPAD 11:**

LOCATION: \_\_\_\_\_ AREA: \_\_\_\_\_ TESTED: \_\_\_\_\_

**KEYPAD 12:**

LOCATION: \_\_\_\_\_ AREA: \_\_\_\_\_ TESTED: \_\_\_\_\_

**KEYPAD 13:**

LOCATION: \_\_\_\_\_ AREA: \_\_\_\_\_ TESTED: \_\_\_\_\_

**KEYPAD 14:**

LOCATION: \_\_\_\_\_ AREA: \_\_\_\_\_ TESTED: \_\_\_\_\_

**KEYPAD 15:**

LOCATION: \_\_\_\_\_ AREA: \_\_\_\_\_ TESTED: \_\_\_\_\_

**KEYPAD 16:**

LOCATION: \_\_\_\_\_ AREA: \_\_\_\_\_ TESTED: \_\_\_\_\_

Keypad addresses set differently? \_\_\_\_\_

**CONTROLLER POWER UP**

System Grounded to good ground? \_\_\_\_\_

Runs with battery disconnected? \_\_\_\_\_

Runs on battery with transformer unplugged? \_\_\_\_\_

**TELEPHONE CHECKOUT**

TELCO surge arrestor properly grounded? \_\_\_\_\_

Incoming lines to TELCO arrestor first? \_\_\_\_\_

PHONE LINE LED off when phones are hung up? \_\_\_\_\_

Voice menu on in-house phones? \_\_\_\_\_

Customer's ADDRESS in memory (# 8 8)?  
(# 8 9 + Master code to record) \_\_\_\_\_

All in-house phones checked ? \_\_\_\_\_

**CONTROL CHECK OUT**

HOUSE CODE: \_\_\_\_\_ set to AREA: \_\_\_\_\_

LOCATION	TESTED
Unit #1: _____	_____
Unit #2: _____	_____
Unit #3: _____	_____
Unit #4: _____	_____
Unit #5: _____	_____
Unit #6: _____	_____
Unit #7: _____	_____
Unit #8: _____	_____
Unit #9: _____	_____
Unit #10: _____	_____
Unit #11: _____	_____
Unit #12: _____	_____
Unit #13: _____	_____
Unit #14: _____	_____
Unit #15: _____	_____
Unit #16: _____	_____

For UNIT NUMBERS 17-32 the House Code is automatically set to one greater than the house code used above.

This group is set to AREA: \_\_\_\_\_

Unit #17: _____	_____
Unit #18: _____	_____
Unit #19: _____	_____



Unit #20: \_\_\_\_\_

Unit #21: \_\_\_\_\_

Unit #22: \_\_\_\_\_

Unit #23: \_\_\_\_\_

Unit #24: \_\_\_\_\_

Unit #25: \_\_\_\_\_

Unit #26: \_\_\_\_\_

Unit #27: \_\_\_\_\_

Unit #28: \_\_\_\_\_

Unit #29: \_\_\_\_\_

Unit #30: \_\_\_\_\_

Unit #31: \_\_\_\_\_

Unit #32: \_\_\_\_\_

For UNIT NUMBERS 33-48 the House Code is automatically set to one greater than the house code used above.

This group is set to AREA: \_\_\_\_\_

Unit #33: \_\_\_\_\_

Unit #34: \_\_\_\_\_

Unit #35: \_\_\_\_\_

Unit #36: \_\_\_\_\_

Unit #37: \_\_\_\_\_

Unit #38: \_\_\_\_\_

Unit #39: \_\_\_\_\_

Unit #40: \_\_\_\_\_

Unit #41: \_\_\_\_\_

Unit #42: \_\_\_\_\_  
Unit #43: \_\_\_\_\_  
Unit #44: \_\_\_\_\_  
Unit #45: \_\_\_\_\_  
Unit #46: \_\_\_\_\_  
Unit #47: \_\_\_\_\_  
Unit #48: \_\_\_\_\_

For UNIT NUMBERS 49-64 the House Code is automatically set to one greater than the house code used above.

This group is set to AREA: \_\_\_\_\_

Unit #49: \_\_\_\_\_  
Unit #50: \_\_\_\_\_  
Unit #51: \_\_\_\_\_  
Unit #52: \_\_\_\_\_  
Unit #53: \_\_\_\_\_  
Unit #54: \_\_\_\_\_  
Unit #55: \_\_\_\_\_  
Unit #56: \_\_\_\_\_  
Unit #57: \_\_\_\_\_  
Unit #58: \_\_\_\_\_  
Unit #59: \_\_\_\_\_  
Unit #60: \_\_\_\_\_  
Unit #61: \_\_\_\_\_  
Unit #62: \_\_\_\_\_  
Unit #63: \_\_\_\_\_  
Unit #64: \_\_\_\_\_

For UNIT NUMBERS 65-80 the House Code is automatically set to one greater than the house code used above.

This group is set to AREA: \_\_\_\_\_

- Unit #65: \_\_\_\_\_
- Unit #66: \_\_\_\_\_
- Unit #67: \_\_\_\_\_
- Unit #68: \_\_\_\_\_
- Unit #69: \_\_\_\_\_
- Unit #70: \_\_\_\_\_
- Unit #71: \_\_\_\_\_
- Unit #72: \_\_\_\_\_
- Unit #73: \_\_\_\_\_
- Unit #74: \_\_\_\_\_
- Unit #75: \_\_\_\_\_
- Unit #76: \_\_\_\_\_
- Unit #77: \_\_\_\_\_
- Unit #78: \_\_\_\_\_
- Unit #79: \_\_\_\_\_
- Unit #80: \_\_\_\_\_

For UNIT NUMBERS 81-96 the House Code is automatically set to one greater than the house code used above.

This group is set to AREA: \_\_\_\_\_

- Unit #81: \_\_\_\_\_
- Unit #82: \_\_\_\_\_
- Unit #83: \_\_\_\_\_
- Unit #84: \_\_\_\_\_

Unit #85: \_\_\_\_\_  
Unit #86: \_\_\_\_\_  
Unit #87: \_\_\_\_\_  
Unit #88: \_\_\_\_\_  
Unit #89: \_\_\_\_\_  
Unit #90: \_\_\_\_\_  
Unit #91: \_\_\_\_\_  
Unit #92: \_\_\_\_\_  
Unit #93: \_\_\_\_\_  
Unit #94: \_\_\_\_\_  
Unit #95: \_\_\_\_\_  
Unit #96: \_\_\_\_\_

For UNIT NUMBERS 97-112 the House Code is automatically set to one greater than the house code used above.

This group is set to AREA: \_\_\_\_\_

Unit #97: \_\_\_\_\_  
Unit #98: \_\_\_\_\_  
Unit #99: \_\_\_\_\_  
Unit #100: \_\_\_\_\_  
Unit #101: \_\_\_\_\_  
Unit #102: \_\_\_\_\_  
Unit #103: \_\_\_\_\_  
Unit #104: \_\_\_\_\_  
Unit #105: \_\_\_\_\_  
Unit #106: \_\_\_\_\_

Unit #107: \_\_\_\_\_  
Unit #108: \_\_\_\_\_  
Unit #109: \_\_\_\_\_  
Unit #110: \_\_\_\_\_  
Unit #111: \_\_\_\_\_  
Unit #112: \_\_\_\_\_

For UNIT NUMBERS 113-128 the House Code is automatically set to one greater than the house code used above.

This group is set to AREA: \_\_\_\_\_

Unit #113: \_\_\_\_\_  
Unit #114: \_\_\_\_\_  
Unit #115: \_\_\_\_\_  
Unit #116: \_\_\_\_\_  
Unit #117: \_\_\_\_\_  
Unit #118: \_\_\_\_\_  
Unit #119: \_\_\_\_\_  
Unit #120: \_\_\_\_\_  
Unit #121: \_\_\_\_\_  
Unit #122: \_\_\_\_\_  
Unit #123: \_\_\_\_\_  
Unit #124: \_\_\_\_\_  
Unit #125: \_\_\_\_\_  
Unit #126: \_\_\_\_\_  
Unit #127: \_\_\_\_\_  
Unit #128: \_\_\_\_\_

Unit #193: _____	Type: _____	Area: _____
Unit #194: _____	Type: _____	Area: _____
Unit #195: _____	Type: _____	Area: _____
Unit #196: _____	Type: _____	Area: _____
Unit #197: _____	Type: _____	Area: _____
Unit #198: _____	Type: _____	Area: _____
Unit #199: _____	Type: _____	Area: _____
Unit #200: _____	Type: _____	Area: _____

**CUSTOMER INFORMATION**

Customer knows how to arm/disarm? \_\_\_\_\_

Customer knows how to change codes? \_\_\_\_\_

Customer knows how to get menu on phone? \_\_\_\_\_

Customer satisfied with installation? \_\_\_\_\_

Customer Manual Delivered? \_\_\_\_\_

Tools/trash picked up? \_\_\_\_\_

NOTES: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

\_\_\_\_\_  
Installer

\_\_\_\_\_  
Signature

\_\_\_\_\_  
Date

**DIGITAL COMMUNICATOR CODE SHEET**  
**INFORMATION FOR CENTRAL STATION**

Date: \_\_\_\_\_

Subscriber Name: \_\_\_\_\_  
Address 1: \_\_\_\_\_  
Address 2: \_\_\_\_\_  
City, State, Zip: \_\_\_\_\_  
Home #: \_\_\_\_\_ Work #: \_\_\_\_\_  
Password: \_\_\_\_\_

Installer Name: \_\_\_\_\_  
Address 1: \_\_\_\_\_  
Address 2: \_\_\_\_\_  
City, State, Zip: \_\_\_\_\_  
Phone #: \_\_\_\_\_ Beeper #: \_\_\_\_\_

Subscriber's Notification List:

1. Name: \_\_\_\_\_  
Phone #: \_\_\_\_\_  
Relationship: \_\_\_\_\_
2. Name: \_\_\_\_\_  
Phone #: \_\_\_\_\_  
Relationship: \_\_\_\_\_
3. Name: \_\_\_\_\_  
Phone #: \_\_\_\_\_  
Relationship: \_\_\_\_\_

Subscriber Equipment: **OnQ Technologies, Inc. - Model 1050**

Notes: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

First Phone #: \_\_\_\_\_  
First Account #: \_\_\_\_\_  
Second (Backup) Phone #: \_\_\_\_\_  
Second (Backup) Account #: \_\_\_\_\_

Communicator Type (1400 Hz or 2300 Hz): \_\_\_\_\_

TWO-WAY AUDIO: \_\_\_\_\_ YES \_\_\_\_\_ NO  
REPORT OPEN/CLOSE: \_\_\_\_\_ YES \_\_\_\_\_ NO

24 HOUR TEST: \_\_\_\_\_ YES \_\_\_\_\_ NO TEST TIME: \_\_\_\_\_



<b>CODE</b>	<b>ZONE</b>	<b>DESCRIPTION</b>	<b>ACTION TO TAKE</b>
98	TEST CODE	_____	_____
01	ZONE 1:	_____	_____
02	ZONE 2:	_____	_____
03	ZONE 3:	_____	_____
04	ZONE 4:	_____	_____
05	ZONE 5:	_____	_____
06	ZONE 6:	_____	_____
07	ZONE 7:	_____	_____
08	ZONE 8:	_____	_____
09	ZONE 9:	_____	_____
10	ZONE 10:	_____	_____
11	ZONE 11:	_____	_____
12	ZONE 12:	_____	_____
13	ZONE 13:	_____	_____
14	ZONE 14:	_____	_____
15	ZONE 15:	_____	_____
16	ZONE 16:	_____	_____
17	ZONE 17:	_____	_____
18	ZONE 18:	_____	_____
19	ZONE 19:	_____	_____
20	ZONE 20:	_____	_____
21	ZONE 21:	_____	_____
22	ZONE 22:	_____	_____
23	ZONE 23:	_____	_____
24	ZONE 24:	_____	_____
25	ZONE 25:	_____	_____
26	ZONE 26:	_____	_____

<b>CODE</b>	<b>ZONE</b>	<b>DESCRIPTION</b>	<b>ACTION TO TAKE</b>
27	ZONE 27:	_____	_____
28	ZONE 28:	_____	_____
29	ZONE 29:	_____	_____
30	ZONE 30:	_____	_____
31	ZONE 31:	_____	_____
32	ZONE 32:	_____	_____
B0	ZONE 33:	_____	_____
B1	ZONE 34:	_____	_____
B2	ZONE 35:	_____	_____
B3	ZONE 36:	_____	_____
B4	ZONE 37:	_____	_____
B5	ZONE 38:	_____	_____
B6	ZONE 39:	_____	_____
B7	ZONE 40:	_____	_____
B8	ZONE 41:	_____	_____
B9	ZONE 42:	_____	_____
BB	ZONE 43:	_____	_____
BC	ZONE 44:	_____	_____
BD	ZONE 45:	_____	_____
BE	ZONE 46:	_____	_____
BF	ZONE 47:	_____	_____
C0	ZONE 48:	_____	_____
C1	ZONE 49:	_____	_____
C2	ZONE 50:	_____	_____
C3	ZONE 51:	_____	_____
C4	ZONE 52:	_____	_____
C5	ZONE 53:	_____	_____

<b>CODE</b>	<b>ZONE</b>	<b>DESCRIPTION</b>	<b>ACTION TO TAKE</b>
C6	ZONE 54:	_____	_____
C7	ZONE 55:	_____	_____
C8	ZONE 56:	_____	_____
C9	ZONE 57:	_____	_____
CB	ZONE 58:	_____	_____
CC	ZONE 59:	_____	_____
CD	ZONE 60:	_____	_____
CE	ZONE 61:	_____	_____
CF	ZONE 62:	_____	_____
D0	ZONE 63:	_____	_____
D1	ZONE 64:	_____	_____
D2	ZONE 65:	_____	_____
D3	ZONE 66:	_____	_____
D4	ZONE 67:	_____	_____
D5	ZONE 68:	_____	_____
D6	ZONE 69:	_____	_____
D7	ZONE 70:	_____	_____
D8	ZONE 71:	_____	_____
D9	ZONE 72:	_____	_____
DB	ZONE 73:	_____	_____
DC	ZONE 74:	_____	_____
DD	ZONE 75:	_____	_____
DE	ZONE 76:	_____	_____
DF	ZONE 77:	_____	_____
E0	ZONE 78:	_____	_____
E1	ZONE 79:	_____	_____
E2	ZONE 80:	_____	_____

<b>CODE</b>	<b>ZONE</b>	<b>DESCRIPTION</b>	<b>ACTION TO TAKE</b>
E3	ZONE 81:	_____	_____
E4	ZONE 82:	_____	_____
E5	ZONE 83:	_____	_____
E6	ZONE 84:	_____	_____
E7	ZONE 85:	_____	_____
E8	ZONE 86:	_____	_____
E9	ZONE 87:	_____	_____
EB	ZONE 88:	_____	_____
EC	ZONE 89:	_____	_____
ED	ZONE 90:	_____	_____
EE	ZONE 91:	_____	_____
EF	ZONE 92:	_____	_____
F0	ZONE 93:	_____	_____
F1	ZONE 94:	_____	_____
F2	ZONE 95:	_____	_____
F3	ZONE 96:	_____	_____
81	FREEZE ALARM	_____	_____
82	FIRE EMERG	_____	_____
83	POLICE EMERG	_____	_____
84	AUX EMERG	_____	_____
85	DURESS	_____	_____
86	BATTERY LOW	_____	_____
87	FIRE ZONE TROUBLE	_____	_____
99	CANCEL CODE	_____	_____
40	OTHER OPEN	_____	_____
41	USER 1 OPEN	_____	_____

<b>CODE</b>	<b>ZONE</b>	<b>DESCRIPTION</b>	<b>ACTION TO TAKE</b>
42	USER 2 OPEN		
43	USER 3 OPEN		
44	USER 4 OPEN		
45	USER 5 OPEN		
46	USER 6 OPEN		
47	USER 7 OPEN		
48	USER 8 OPEN		
49	USER 9 OPEN		
50	USER 10 OPEN		
51	USER 11 OPEN		
52	USER 12 OPEN		
53	USER 13 OPEN		
54	USER 14 OPEN		
55	USER 15 OPEN		
56	USER 16 OPEN		
60	OTHER CLOSE		
61	USER 1 CLOSE		
62	USER 2 CLOSE		
63	USER 3 CLOSE		
64	USER 5 CLOSE		
65	USER 5 CLOSE		
66	USER 6 CLOSE		
67	USER 7 CLOSE		
68	USER 8 CLOSE		
69	USER 9 CLOSE		
70	USER 10 CLOSE		

<b>CODE</b>	<b>ZONE</b>	<b>DESCRIPTION</b>	<b>ACTION TO TAKE</b>
71	USER 11 CLOSE	_____	_____
72	USER 12 CLOSE	_____	_____
73	USER 13 CLOSE	_____	_____
74	USER 14 CLOSE	_____	_____
75	USER 15 CLOSE	_____	_____
76	USER 16 CLOSE	_____	_____